



WyreStorm HD over IP Solutions



■ HD over IP AV distribution solution
utilising H.264 compression for
AV switching and video wall
functionality over a LAN

Part Number NHD-000-CTL
 NHD-200-TX
 NHD-200-RX
 NHD-210-RX

Instruction Manual



Thank you for choosing this WyreStorm product.
Please read these instructions carefully before installing to avoid complications later.

Contents

1	Introduction
2	Features
3	Safety Precautions
4	In the Box
5	Before Installation
6	Specifications
7	Panel Description
8	Connection
9	Typical Application
	i. One Encoder to One Decoder
	ii. One Encoder to Multiple Decoders
	iii. Multiple Encoders to Multiple Decoders
	iv. Video Wall
10	Switch Settings and Requirements
11	NHD-000-CTL Browser Configuration & Control
	i. Matrix Switching Commands
	ii. TX/RX Settings
	iii. CTL Settings
12	NetworkHD™ Console Configuration
	i. NetworkHD™ Console Software Installation
	ii. Searching Devices
	iii. Setting Device Parameters
	iv. Device Settings
	v. Creating Scenes
	vi. Sample Video Wall Set Up
	vii. Video Wall Configuration
	viii. Video Wall Properties
	ix. Configuration File Management
	x. Serial Control
	xi. CEC Control
	xii. Viewing the Encoders Preview Stream
	xiii. Log
13	Additional Information
14	NetworkHD™ Protocol
15	Troubleshooting
16	FAQ
17	Maintenance
18	Provided Service
19	Mail In Service
20	Warranty

21	Warranty Limits and Exclusions
-----------	--------------------------------

22	Disclaimer
-----------	------------

23	Installation Reference Logs
-----------	-----------------------------

1. Introduction

WyreStorm® NetworkHD™ 200 is our flagship H.264 HD over IP distribution platform. With its simple system configuration and powerful video wall functionality it is the best all round solution for commercial AV installs. Enabling the distribution of multiple video formats over a dedicated IP network switch for commercial AV applications.

NetworkHD™ 200 series facilitates the transmission of an HDMI, DVI, Component & VGA signals (including Full HD 1080p video with 2.1 audio) to any number of HDMI displays over standard Ethernet (Cat5e/6) infrastructure. The NHD-200-RX enables the display of a single image on a display whilst the NHD-210-RX decoder adds video wall playback to the system.

The modular system architecture of NetworkHD™ 200 removes the limitations of a traditional fixed platform I/O matrix system without compromising quality or reliability, whilst offering significant cost savings when designing large scale installations. Adding encoders and decoders as required enables the system to grow with the needs of the application.

NetworkHD™ 200 uses multiple technologies to automatically configure and discover system components, making setup a breeze. Functioning on 10/100 or Gigabit Layer2 SMART switches, NetworkHD™ 200 does not require advanced integrator network experience to install, nor does it require complicated VLAN configurations or PC software, making it one of the simplest HD over IP systems available. Configuring network switches takes minutes through your browser and even the largest distributions can be quickly and easily configured and expanded.

The NHD-000-CTL controller creates a simple, single interface to configure, manage and control the entire NetworkHD™ 200 system, whilst also capable of fully integrating with leading control brands including WyreStorm Enado™ for the highest quality total HD distribution and control solution over a network.

For further information on this product and other WyreStorm ranges, visit our website or download our latest product guide at wyrestorm.com

2. Features

- Highly scalable, visually lossless HD over IP solution using the most efficient compression technology to allow for very large commercial AV deployments
- Powerful video wall functionality (NHD-210-RX only) up to 4 x 4 displays.
- Multi-format DVI-I input selectable to HDMI, DVI, Component, VGA & Composite input
- Plug and Play setup with automatic networking configuration and auto discovery of components
- Quick Sync™ technology for virtually instantaneous, seamless switching
- CEC One-Touch Play & Standby or RS-232 control of connected displays
- Supports video previewing on a PC or third party device. NetworkHD™ 200 outputs simultaneous IP streams. One full resolution for the NHD-200-RX. The other small one supports resolutions of 352 x 288 @ 5Hz to easily preview a video from the encoder on a PC or Mac
- Use with the new NHD-000-CTL controller for simple configuration and control via the LAN, as well as for allowing control from third party control system such as AMX, Crestron, Control4, RTI & WyreStorm™ Enado.
- Supports PoE to enable remote powering from POE network switches, eliminating the need for a nearby power outlet
- Full PC control suite available free of charge at wyrestorm.com
- Supports HDCP
- Audio Breakout on both Encoder & Decoder
- Configurable encoding bit rate up to 40 Mbps

3. Safety Precautions



WARNING

To reduce the risk of fire, electric shock or product damage:

1. Ventilation is crucial to consistent operation of this product. Units should be mounted with at least (2.5cm) 1 inch clearance of vents. WyreStorm highly recommends the use of the NHD-000-RACK for absolute correct mounting best practice.
2. Do not expose this apparatus to rain, moisture, sprays, drips or splashes and ensure that no objects containing liquids are placed on the apparatus, including cups, glasses and vases.
3. Do not place this unit in a confined space such as enclosed shelving, cabinets or bookshelves. Ensure the unit is adequately ventilated.
4. To prevent the risk of electric shock or fire hazard due to overheating, do not cover the unit or obstruct ventilation openings with material, newspaper, cardboard or anything that may restrict airflow into the unit.
5. Do not install near external heat sources such as radiators, heat registers, boilers or any device that produces heat such as amplifiers or computers and do not place near sources of naked flame.
6. Unplug apparatus from power supply during lightening storms or when unused for long periods of time.
7. Protect the power cable from being walked on, pinched or restricted in any way, especially at plug connections.
8. Only use attachments/accessories specified by the manufacturer.
9. Units contain non-servicable parts - Refer all servicing to qualified service personnel

4. In the Box

NHD-200-TX

1 x NHD-200-TX Main Unit
 1 x Power Adapter (12V 1A DC)
 3 x Detachable International Plugs
 1 x HDMI to DVI Converter
 1 x VGA to DVI Converter
 1 x Component to DVI Converter
 2 x Phoenix Connector (Male, 3.5 mm, 3 pin)
 2 x Mounting Ears

NHD-200-RX

1 x NHD-200-RX Main Unit
 1 x Power Adapter (12V 1A DC)
 3 x Detachable International Plug s
 3 x Phoenix Connector (Male, 3.5 mm, 3 pin)
 2 x Mounting Ears

NHD-210-RX

1 x NHD-210-RX Main Unit
 1 x Power Adapter (12V 1A DC)
 3 x Detachable International Plug s
 3 x Phoenix Connector (Male, 3.5 mm, 3 pin)
 2 x Mounting Ears

NHD-000-CTL

1 x NHD-000-CTL Main Unit
 1 x Power Adapter (12V 1A DC)
 3 x Detachable International Plug s
 1 x Phoenix Connector (Male, 3.5 mm, 4 pin)
 2 x Mounting Ears

5. Before Installation

Introduction

This guide is intended for installation project managers to ensure you are aware of WyreStorm's installation best practice guidelines that we know will improve the installation experience. These issues have been gathered from thousands of installation reports, support calls and our own personal experiences to prevent issues that cost hours in troubleshooting and protracted site visits to fix.

Preparation

Build and test the rack and all hardware components off site. Doing so will find any issues before moving to the hectic and time sensitive environment of the install itself. Knowing that a unit was working properly before makes it far easier to pinpoint the cause of the problem saving time and money.

Network Equipment & Switches

NetworkHD™ can be operated with recommended Layer 2 Gigabit Smart Switches provided the overall switching capacity or backplane capacity of the switch meets the requirements of the number of encoders/decoders you have on your network.

WyreStorm NetworkHD is built to run over a standard network infrastructure, however the quality of this infrastructure is critical. We have tested many brands of switches all of which perform well in small system configurations of around 10 Encoders and Decoders. However, for larger installations, WyreStorm highly recommends using CISCO SG500 or CATALYST series switches.

NetworkHD requires a Layer 2 managed switch with support for Multicast & IGMP snooping enabled. Do not connect any encoders to the switch until this has been configured. For recommended switches and PDF configuration guides please see the 'downloads' section of any NetworkHD device at wyrestorm.com.

It is not necessary to change the IP addresses of the TX and RX units – AutoIP is used to configure correct IP addresses. DHCP or Static IP addresses are not recommended unless absolutely required. Failure to note or errors in the IP settings of a unit may result in a complicated reset procedure.

Most NetworkHD installations use POE (Power Over Ethernet) to power the RX & TX units. NetworkHD 100 & 200 components are Class 0 rated POE devices meaning that they can require up to 15.4W of power each, however their real power draw is between 5-7W.

In order to calculate the number of devices that can be used on a switch please divide the total POE power capability of the switch by 15.4 and round down. For Example the CISCO SG300-52P with a POE power output of 375W: $375 / 15.4 = 24.35$. Therefore 24 devices can be powered by this switch.

In order to have all ports powered by POE on a switch an MP series should be used in this example an SG300-52MP which provides 740W. $740 / 15.4 = 48$. Therefore 48 devices can be powered by this switch.

Each NHD-100-TX encoder will produce up to 50Mb/s of data > therefore 10 x encoders will require 10 x 50Mb/s = **0.5 Gbps**.

! If you are unsure about the network requirements for your NetworkHD™ system please contact WyreStorm or your local WyreStorm distribution partner for support. WyreStorm are not liable if network bandwidth is to blame for poor performance from the NetworkHD™ system.

NetworkHD™ does not require multiple VLANs to be configured. Third-party controllers communicate directly with the NHD-000-CTL rather than the Ethernet switch.

Visit wyrestorm.com for guides on detailed switch configuration and recommended switch suggestions for different sized NetworkHD™ systems.

Power

Your installation is nothing without power. Use a UPS (Uninterruptible Power Supply) to ensure a clean, consistent power supply to all components in the rack. Be sure to calculate your total load and run time requirements ahead and leave enough room in the rack.

Heat

High temperatures are the biggest killer of electronic products. Just a 3° Celsius rise in external temperature can equate to a 15° degree rise in internal temperature and trigger thermal runaway. Ensure proper rack design and passive or active cooling strategies are used to properly move heat away from the components in the rack. Poor installation of cables looks messy and creates hotspots that prevent heat moving away from components – avoid this at all costs.

The NHD-IP-RACK & NHD-000-RACK have been designed for optimal mounting of the NetworkHD Encoders in the rack and should always be used. Encoders and decoders should never be laid flat or stacked on top of each other. At least 1.5 inches of clearance should be left by the vents to ensure adequate airflow through the units.

Software

Where possible WyreStorm ship all components with the most up to date firmware and software, however before starting any installation please check the downloads section of the products on WyreStorm.com to ensure there are no updates to your system components. Please also try to use the latest firmware on all related hardware – particularly switches and TVs. Please check with the relevant manufacturer for upgrade instructions.

Redundancy

With all the planning in the world, even the most experienced installers make mistakes and accidents will always happen. For this reason, it is best practice to always run two cables to each Decoder location. This may increase the cost of cabling but is nothing compared to replacing a single or even multiple defective cables that have been sealed into the wall.

Although WyreStorm are incredibly proud of the reliability and robustness of our products from time to time units can fail. Therefore, mission critical products such as the CTL and Decoders in hard or impossible to access locations should be installed with spare, redundant units that can be swapped to if required.

Mounting/Installation

All WyreStorm products should be mounted so that the logo and text printed on the unit is correctly aligned. This will allow for the optimal airflow through the product. As already stated the vents should not be obstructed with adequate clearance. Units should be secured using suitable fixings such as those supplied in the box.

Source & Display settings

WyreStorm NetworkHD components use the highest quality encoders available to provide visually lossless compression over a large number of displays. However, the compression can only be as good as the source content that is put in. NetworkHD 100/200 series use H.264 compression that is not compatible with interlaced sources. Please ensure that all source content is set to Progressive scan (720p/1080p) and not interlaced (1080i).

On the displays and sources – low power modes should be disabled to ensure the system is always fed with content. The customer does not want to be troubleshooting if the source has gone into standby.

The displays should have CEC enabled so that NetworkHD can power them on and off. This setting is called different things by different manufacturers and is not always enabled by default. Any screens that are used in video walls must also have Over Scan disabled. This setting is always enabled by default and often hidden in advanced settings menus. Without it disabled the video wall will not align.

Testing & Certification

WyreStorm products are manufactured and testing to the highest standards but the best installation environment is paramount to successful installation. The only way to guarantee the installation is fit for purpose is to test and certify cables. All IT cable companies will certify cables throughout a network as standard, yet they are passing a fraction of the data in short bursts that NetworkHD transmits 24/7. Although testing a cable proves that it is correctly terminated, it does not show how much interference on the run is affecting bandwidth. Certification of every cable should always be performed before and after walls are sealed.

Cable Type & 4K support

WyreStorm are always striving to improve our technologies and although your system is the best available today – what lies ahead is not always clear. All you can do is prepare your installation as best you can for future technologies. Running extra cables to all display locations to provide extra bandwidth for future technologies. Ensuring source components are located next to transmitters with HDMI cables that are as short as possible as HDMI distances will reduce as content bandwidth increases. Use trunking so that cables can be easily replaced down the line. Never seal HDMI cables in the wall as they cannot be re-terminated or replaced easily.

6. Specifications

NHD-200-TX

TECHNICAL	
Input Video Ports	1 x DVI IN
Input Video Type	HDMI, DVI 1.0, VGA, Component
Input Video Resolutions	<p>HDMI: 640 x 480 @ 60Hz, 480p @ 60Hz, 576p @ 50Hz, 800 x 600 @ 60Hz, 1024 x 768 @ 60Hz, 720p @ 50Hz, 720p @ 60Hz, 1280 x 800 @ 60Hz, 1280 x 1024 @ 60Hz, 1360 x 768 @ 60Hz, 1366 x 768 @ 60Hz, 1400 x 1050 @ 60Hz, 1440 x 900 @ 60Hz, 1680 x 1050 @ 60Hz, 1080p @ 24Hz, 1080p @ 25Hz, 1080p @ 30Hz, 1080p @ 50Hz, 1080p @ 60Hz, 1920 x 1200 @ 60Hz</p> <p>DVI: 640 x 480 @ 60Hz, 480p @ 60Hz, 576P @ 50Hz, 800 x 600 @ 60Hz, 1024 x 768 @ 60Hz, 720p @ 50Hz, 720p @ 60Hz, 1280 x 800 @ 60Hz, 1280 x 1024 @ 60Hz, 1360 x 768 @ 60Hz, 1366 x 768 @ 60Hz, 1400 x 1050 @ 60Hz, 1440 x 900 @ 60Hz, 1680 x 1050 @ 60Hz, 1080p @ 24Hz, 1080p @ 25Hz, 1080p @ 30Hz, 1080p @ 50Hz, 1080p @ 60Hz, 1920 x 1200 @ 60Hz</p> <p>VGA: 640 x 480 @ 60Hz, 800 x 600 @ 60Hz, 1024 x 768 @ 60Hz, 1280 x 1024 @ 60Hz, 1280 x 720 @ 60Hz, 1280 x 768 @ 60Hz, 1280 x 800 @ 60Hz, 1360 x 768 @ 60Hz, 1366 x 768 @ 60Hz, 1440 x 900 @ 60Hz, 1400 x 1050 @ 60Hz, 1680 x 1050 @ 60Hz, 1920 x 1080 @ 60Hz, 1920 x 1200 @ 60Hz</p> <p>Component: 720 x 480p @ 60Hz, 720 x 576p @ 50Hz, 1280 x 720p @ 50Hz, 1280 x 720p @ 60Hz</p>
Input Video Signal	0.5 ~ 1.2 V p-p
Encoding Data Rate	Up to 30 Mbps, configurable
Output Video Ports	1 x LAN
Output Video Type	H.264/MPEG-4 AVC
Output Video Resolutions	Large IP stream: 480p @ 60Hz ~ 1920 x 1200 @ 60Hz Small IP stream: 352 x 288 @ 5Hz
Video Impedance	100 Ω
Input DDC Signal	5 V p-p (TTL)
End-to-End Time Latency	<ul style="list-style-type: none"> About 60 ms-90 ms (Low latency mode) About 250 ms-300 ms (High quality mode)
AUDIO	
Input Audio Ports	1 x Audio Jack
Input Audio Format	Stereo
Output Audio Ports	1 x Phoenix Connector
Output Audio Format	Stereo

CONTROL	
Control Method	Rear panel source switch, PC configurator and RS-232
GENERAL	
Operating Temperature	+32°F ~ +113°F (0°C ~ +45°C) 10% ~ 90%, non-condensing
Storage Temperature	-4°F ~ 140°F (-20°C ~ +70°C) 10% ~ 90%, non-condensing
Power	12V 1A DC
Power Consumption	6W (Max.)
ESD Protection	Human body model: <ul style="list-style-type: none"> • ±8kV (air-gap discharge) • ±4kV (contact discharge)
Surge Protection	Voltage ±1 kV
Case Dimensions (WxHxD)	310mm x 76mm x 180mm / 12.2" x 3.0" x 7.1"
Product Dimensions (WxHxD)	200mm x 25 mm x 94mm / 7.9" x 1.0" x 3.7"
Weight	0.48 Kg
Certification	CE, FCC, RoHS compliant

NHD-200-RX & NHD-210-RX

TECHNICAL	
Input Video Ports	1 x LAN
Input Video Type	H.264/MPEG-4 AVC
Input Video Resolutions	480p @ 60Hz ~ 1920 x 1200 @ 60Hz
Output Video Ports	1 x HDMI
Output Video Type	HDMI 1.3
Output Video Resolutions	HDMI 480p @ 60Hz, 576p @ 50Hz, 800 x 600 @ 60Hz, 1024 x 768 @ 60Hz, 720p @ 50Hz, 720p @ 60Hz, 1280 x 800 @ 60Hz, 1280 x 1024 @ 60Hz, 1366 x 768 @ 60Hz, 1440 x 900 @ 60Hz, 1600 x 1200 @ 60Hz, 1680 x 1050 @ 60Hz, 1080p @ 24Hz, 1080p @ 25Hz, 1080p @ 30Hz, 1080p @ 50Hz, 1080p @ 60Hz, 1920 x 1200 @ 60Hz
Video Impedance	100 Ω
End-to-End Time Latency	<ul style="list-style-type: none"> • About 60 ms-90 ms (Low latency mode) • About 250 ms-300 ms (High quality mode)
AUDIO	
Input Audio Ports	1 x LAN
Input Audio Format	Audio embedded in streaming media input
Output Audio Ports	1 x Phoenix Connector
Output Audio Format	Stereo

CONTROL	
Control Method	PC configurator and RS-232
GENERAL	
Operating Temperature	+32°F ~ +113°F (0°C ~ +45°C) 10% ~ 90%, non-condensing
Storage Temperature	-4°F ~ 140°F (-20°C ~ +70°C) 10% ~ 90%, non-condensing
Power	12V 1A DC
Power Consumption	6W (Max.)
ESD Protection	Human body model: • ±8kV (air-gap discharge) • ±4kV (contact discharge)
Surge Protection	Voltage ±1 kV
Case Dimensions (WxHxD)	310mm x 76mm x 180mm / 12.2" x 3.0" x 7.1"
Product Dimensions (WxHxD)	228mm x 25 mm x 111mm / 9.0" x 1.0" x 4.4"
Weight	0.6 Kg
Certification	CE, FCC, RoHS compliant

7. Panel Description

NHD-000-CTL Front

1 Reset Button

2 Status Indicator:
ON - NHD-000-CTL works properly.
Off - NHD-000-CTL is not in the normal working state.

3 Power indicator:
ON - NHD-000-CTL is powered on.
Off - NHD-000-CTL is powered off.



NHD-000-CTL Rear

- 1** AV LAN (POE) - connect to the same switch/VLAN as the NHD Encoders & Decoders
- 2** CONTROL LAN (POE) - connect to the same switch/VLAN as the control system and configuring PCs.

- 3** RS232 - connects to a RS-232 device such as a computer for debugging and upgrading the NHD-000-CTL
- 4** Power Input - Connects to a power adapter, 12V 1A DC.




NHD-200-TX Front

- 1** Power indicator:
ON - NHD-200-TX is powered on.
Off - NHD-200-TX is powered off.
- 2** Status Indicator:
ON - NHD-200-TX works properly.
Off - NHD-200-TX is not in the normal working state.



NHD-200-TX Rear

- 1** AV IN - connects to an HDMI, DVI, VGA, Component and video source such as a DVD player or computer. DVI, VGA, Component input can be embedded with the audio from LINE IN.
- 2** LINE IN - connects to an audio input device such as a computer, a Tablet and a
- 3** AUDIO OUT - connects to an audio output device such as an amplifier and an earphone for audio de-embedding output.
- 4** LAN (POE) - used for streaming media output.
- 5** RS-232 - connects to a RS-232 device such as a computer for debugging and upgrading IPE2000.
- 6** DIP Switch - Selects a source input from HDMI, DVI, VGA, Component video sources. **For more information, see Dip Switch Settings section.**
- 7** Power Input - Connects to a power adapter, 12V 1A DC.



Note: If the NHD-200-TX is connected to an HDMI video source and HDMI source input is selected, the audio output from both streaming media and AUDIO OUT is delivered by the HDMI video source rather than the embedded audio of LINE IN.

If the NHD-200-TX is connected to a DVI, VGA, Component video source and the corresponding source input is selected, the audio output from both streaming media and AUDIO OUT is delivered by the embedded audio of LINE IN.

NHD-200-RX / NHD-210-RX Front

- 1** Power indicator:
ON - NHD-200-RX is powered on.
Off - NHD-200-RX is powered off.

2 Status Indicator:
ON - NHD-200-RX works properly.
FLASHING - NHD-200-RX is not linked to NHD-200-TX



NHD-200-RX / NHD-210-RX Rear

- 1** Grounding Screw - connects to the ground for preventing from electric shock and device damage.

2 Power Input - connects to a power adapter, 12V 1A DC.


3 LAN (POE) - connects to a switch for streaming media input.

4 HDMI OUT - connects to an A/V device such as a display for A/V output.

5 AUDIO OUT - connects to an audio output device such as an amplifier and a speaker for de-embedded stereo output.

6 RS-232 1 - connects to a RS-232 device such as a computer for debugging NHD-200-RX.


RS-232 2 - connects to a RS-232 device for serial communication with this device via PC configurator.



8. Connection

! Ensure good quality cabling is used throughout your system, with no electrical interference, bends, twists, kinks, or other issues that may interfere with signal transmission, including the use of patch panels or wall outlets. Cable connectors should also be in good condition and correctly terminated to required standards, with straight cable runs used where possible and plugs securely connected to ports without straining port enclosures.

The presence of any of these factors in your system can jeopardize successful signal distribution and should be eliminated wherever possible.



Ethernet Wiring Guide

The quality of termination for every RJ45 is essential.


Poor terminations leads to intermittent performance and longer install times.

Ethernet Cable Performance Guide										NHD-200 Series
0m	10m	20m	30m	40m	50m	60m	70m	80m	90m	100m
0ft	32ft	65ft	98ft	131ft	164ft	197ft	230ft	262ft	295ft	328ft


9. Typical Application

i. One Encoder To One Decoder


! In order to use NetworkHD™ components in this configuration, the units must first have the signal correctly routed between them. In order to facilitate this, they must first be connected to a network so that the NHD-000-CTL or NetworkHD™ Software Console can be used to route the signal.



ii. One Encoder To Multiple Decoders




iii. Multiple Encoders To Multiple Decoders



TYPICAL APPLICATION

iv. Video Wall



10. Switch Settings & Requirements

Network Equipment & Switches

NetworkHD™ can be operated with recommended Layer 2 Gigabit Smart Switches provided the overall switching capacity or backplane capacity of the switch meets the requirements of the number of encoders/decoders you have on your network.

WyreStorm NetworkHD is built to run over a standard network infrastructure, however the quality of this infrastructure is critical. We have tested many brands of switches all of which perform well in small system configurations of around 10 Encoders and Decoders. However, for larger installations, WyreStorm highly recommends using CISCO SG500 or CATALYST series switches.

NetworkHD requires a Layer 2 managed switch with support for Multicast & IGMP snooping enabled. Do not connect any encoders to the switch until this has been configured. For recommended switches and PDF configuration guides please see the 'downloads' section of any NetworkHD device at wyrestorm.com.

It is not necessary to change the IP addresses of the TX and RX units – AutoIP is used to configure correct IP addresses. DHCP or Static IP addresses are not recommended unless absolutely required. Failure to note or errors in the IP settings of a unit may result in a complicated reset procedure.

Most NetworkHD installations use POE (Power Over Ethernet) to power the RX & TX units. NetworkHD 100 & 200 components are Class 0 rated POE devices meaning that they can require up to 15.4W of power each, however their real power draw is between 5-7W.

In order to calculate the number of devices that can be used on a switch please divide the total POE power capability of the switch by 15.4 and round down. For Example the CISCO SG300-52P with a POE power output of 375W: $375 / 15.4 = 24.35$. Therefore 24 devices can be powered by this switch.

In order to have all ports powered by POE on a switch an MP series should be used in this example an SG300-52MP which provides 740W. $740 / 15.4 = 48$. Therefore 48 devices can be powered by this switch.

Each NHD-100-TX encoder will produce up to 50Mb/s of data > therefore 10 x encoders will require 10 x 50Mb/s = **0.5 Gbps**.

! If you are unsure about the network requirements for your NetworkHD™ system please contact WyreStorm or your local WyreStorm distribution partner for support.

WyreStorm are not liable if network bandwidth is to blame for poor performance from the NetworkHD™ system.

NetworkHD™ does not require multiple VLANs to be configured. Third-party controllers communicate directly with the NHD-000-CTL rather than the Ethernet switch.


Visit wyrestorm.com for guides on detailed switch configuration and recommended switch suggestions for different sized NetworkHD™ systems.

11. NHD-000-CTL Browser Configuration & Control


Ensure all NetworkHD™ components are connected to the network and powered up correctly.

! If you receive a 'server unavailable' system message after entering this address into your browser, ensure your PC is on the same subnet as the CTL box by following these steps:


- 1 Click **Start** menu, go to **Control Panel > Network and Sharing center > Change Adapter Settings > Local Area Connection**. Right click and choose **Properties**.



- 2 Highlight **Internet Protocol Version 4 (TCP/IPv4)** then click **Properties**.




- 3 Check **Use the following IP address**, for the **IP address** enter **192.168.11.x** (if unsure use **192.168.11.5**) Enter **subnet mask** number **255.255.0.0** Click **OK**, then click **OK** again.




- 4 Return to your browser and try entering the default IP again (192.168.11.243)

i. Matrix Switching Commands

Tabs at the top of the Home Screen page are used to access settings for Matrix, TX/RX Settings and System Settings. All pages display Telnet API boxes where commands can be entered from the NetworkHD™ API.



- 1 Click the Load Matrix button, and the table of devices will appear with TX units across the top and the RX down the left hand side.
- 2 Press the box that links each TX & RX to test switching of the video to each RX. Devices who's names starts with EX131 are encoders where as devices that start EX141 are decoders.






Device **online**



Device **offline**



A **green bar** represents corresponding TX and RX are **connected**.
Clicking the green bar changes colour to **clear** to signify the corresponding TX and RX are **disconnected**.



A **red bar** denotes TX/RX connection is being processed



A clear bar signifies corresponding TX and RX are not connected. Click to connect.

! To remove unwanted offline TX or RX units from the scene use the 'X' icon next to its name in the matrix or use the **API command: config set device remove name (name is the alias or the device number)**.


ii. TX/RX Settings

The TX/RX Settings section enables IP settings and alias of each TX and RX to be configured as well as rebooting the system and factory resetting the devices.

Get started by selecting the device to be configured from the list displayed and configure options as below:

GUI Element	Description
Auto IP	Obtain IP address automatically
DHCP	IP address assigned by DHCP server
Static	IP address manually configured
IP Address	IP address of TX/RX
Subnet Mask	Subnet mask of TX/RX
Default Gateway	Default gateway of TX/RX.

Encoder Setup



The screenshot shows the 'Encoder Setup' window. It has a title bar 'Encoder Setup'. Inside, there's a 'Rate Control' section with three radio buttons: CBR (selected), VBR, and FixQP. Below this is an 'Avg bitrate' field with the value '40960' and a range '[2,40960]'. Then there's a 'Profile' section with three radio buttons: H.264 Baseline Profile, H.264 Main Profile, and H.264 High Profile (selected). Below that are 'GOP' and 'FPS' fields, both with the value '60' and ranges '[1,65535]' and '[1,60]' respectively. At the bottom is a 'Transport Type' section with two radio buttons: RAW (selected) and TS. An 'Apply' button is in the bottom right corner.

GUI Element		Description
Rate Control	CBR	Constant Bit Rate - Best used in systems where bandwidth is limited and must match exactly the calculated amount.
	VBR	Variable Bit Rate - Best used for optimal quality/bandwidth usage trade off
	FixQP	Fixed Quantization Parameter - QP is an index used to derive a scaling matrix. Quantization in an H.264 encoder is controlled by a quantization parameter, QP, that ranges from 0 to 51.
Avg Bitrate		The bitrate that the encoder will inject into the network
Profile		The H.264 standard defines a sets of capabilities, which are referred to as profiles, targeting specific classes of applications.
H.264 Baseline Profile		Primarily for applications that require low latency and additional data loss robustness, this profile is most suited for use in video conferencing applications.
H.264 Main Profile		This profile is best used where a compromise between latency and quality is required.
H.264 High Profile		This profile is useful particularly for high-definition/high quality applications where latency is not a concern.
GOP: Group of Pictures		The GOP is a group of successive pictures within a coded video stream. From the pictures contained in it, the visible frames are generated. The higher the value the higher the image quality.
FPS: Frames Per Second		The FPS rating is used to set the frequency at which the encode captures the video stream. The higher the value the higher the image motion quality.
Transport Type		RAW transmits the H.264 bit stream without any container information. TS wraps the bit stream in an MPEG2 container. There is no difference in quality between the two settings.

Alias

! Changing the IP address of TX/RX devices requires a restart for the settings to take affect. Please use the reboot button at the bottom of TX/RX Settings page

Alias' can be used to make identification of system components easier e.g. TV12 or Bluray1. They can also be used instead of device identifiers in API commands.



The screenshot shows the 'Alias' window. It has a title bar 'Alias'. Inside, there's a text input field. An 'Apply' button is in the bottom right corner.

GUI Element	Description
Alias	Rename TX/RX alias for easier identification and use from API commands

! Alias cannot contain any of the following symbols or combinations of letters/numbers: ‘,’ ‘,’ ‘_’ ‘@’, ‘*’, ‘&’, ‘TX’, ‘RX’, ‘,’ ‘NHD’.

Commands

Commands

Factory DefaultRebootShutdown

GUI Element	Description
Factory Default	Restore CTL to factory default settings
Reboot	Reboot CTL
Shutdown	Shutdown CTL

1. CTL Settings contains the settings for the IP control box itself, comprising of two separate network connections for communication with RX/TX devices and communication to the PC/control system.
2. Each setting must be on the same subnet as other devices to enable communication between all devices.
3. The default Auto IP setting is recommended for RX & TX communication - devices will use Bonjour to discover each other

iii. CTL Settings

ScenesTX/RX SettingsController Settings

IP Setup [TX and RX communication]

IP Address: 169.254.1.1

Subnet Mask: 255.255.0.0

Default Gateway: 169.254.1.254

(Attention) After pressing "Apply", this IP control box will automatically reboot for the settings to take effect.

Apply

IP Setup [Telnet client and browser communication]

IP Address: 192.168.11.243

Subnet Mask: 255.255.0.0

Default Gateway: 192.168.11.1

(Attention) After pressing "Apply", this IP control box will automatically reboot for the settings to take effect.

Apply

IP Setup (TX and RX communication)

ScenesTX/RX SettingsController Settings

IP Setup [TX and RX communication]

IP Address: 169.254.1.1

Subnet Mask: 255.255.0.0

Default Gateway: 169.254.1.254

(Attention) After pressing "Apply", this IP control box will automatically reboot for the settings to take effect.

Apply

GUI Element	Description
IP Address	IP address for TX and RX communication
Subnet Mask	Subnet mask for TX and RX communication
Default Gateway	Default gateway for TX and RX communication

IP Setup (Telnet/Browser communication)

IP Setup [Telnet client and browser communication]

IP Address: 192.168.11.243

Subnet Mask: 255.255.0.0

Default Gateway: 192.168.11.1

(Attention) After pressing Apply, this IP control box will automatically reboot for the settings to take effect.

Apply

GUI Element	Description
IP Address	IP address for Telnet client and web
Subnet Mask	Subnet mask for Telnet client and web
Default Gateway	Default gateway for Telnet client and web

Web Password

Web Password

Apply

GUI Element	Description
Web Password	Login password for Web UI management page
Default password	“admin” can be used to restore to factory settings if the user password is unknown

Debug Log

Debug Log

ON OFF

Apply

! Debug files can only be used with the guidance of WyreStorm support.

12. NetworkHD™ Console Configuration

! Included in the download package is the Bonjour SDK installer. This must be installed prior to installing the NetworkHD™ Console software.

i. NetworkHD™ Console Software Installation

1 Download the latest installation package of the NetworkHD™ Configuration Software from **wyrestorm.com** and double-click **Setup.exe** to start the installation process. Complete the installation following the instructions in the installer package.


! Your operating System must be Windows XP or later.

2 The NHD-200-TX, NHD-200-RX and NHD-210-RX are configured by default to IP addresses in the range of **169.254.xxx.xxx**, commonly referred to as **Auto IP addresses**. This is not a DHCP assigned address.


This addressing enables the NHD-000-CTL to automatically discover NHD TX & RX units without any configuration on any network. Changing an RX or TX devices IP settings will prevent this auto discovery and the system components will require a reset.

NOTE: The example below is based on operation using Windows 7 - steps may differ slightly depending on your operating system.


! NetworkHD Console.exe is Windows only. For configuration from other operating systems the NHD-000-CTL must be used. If a 'Windows Security Alert' appears, check both boxes and click 'Allow access' (with Administration Authority).




3 Click **Start** menu, go to **Control Panel > Network and Sharing center > Change Adapter Settings > Local Area Connection**. Right click and choose **Properties**.



4 Highlight **Internet Protocol Version 4 (TCP/IPv4)** then click **Properties**.




5 Check **Use the following IP address**, for the **IP address** enter **169.254.xx.xx** (if unsure use **169.254.2.5**) Enter **subnet mask** number **255.255.0.0** Click **OK**, then click **OK** again.




ii. Searching for devices

1 Open the NetworkHD Console and click **Search** in the Device list area to begin the search – a green progress bar will illustrate process % remaining.




2 When the search is complete authenticated devices will be displayed in the **Devices** area. **Restore** is checked by default.



! If no devices are found, please refer to #1 of the Troubleshooting section of this guide.

iii. Setting Device Parameters


Right click a device in Devices - all available functions are displayed in the pop-up menu.



Operation	Description
Config	Configure device parameters - available only when a single device is selected.
Video Settings	Force resolution and change latency settings.
Audio Settings	This is inoperable with 200 series NetworkHD™.
Update	Incompatible with the 200 series of NetworkHD™, please use the Maintain Tool available with firmware downloads.
Delete	Delete devices - valid when one or more devices are selected.
Turn on	This is inoperable with 200 series NetworkHD™.
Mute	This is inoperable with 200 series NetworkHD™.
Turn on OSD	Incompatible with the 200 series of NetworkHD™.
Turn Off OSD	Incompatible with the 200 series of NetworkHD™.
Background Settings	This is inoperable with 200 series NetworkHD™.

iv. Device Settings

Right click a device in Devices and choose Modify, the Device settings dialog box is displayed.



Devices: NHD-210-RX-70B3D5D595AA

Host Name ID: 70B3D5D595AA

Alias: NHD-210-RX-70B3D5D595AA

IP Address Settings

☒ Auto ☐ DHCP ☐ Static

IP Address: 169 . 254 . 10 . 131

Subnet Mask: 255 . 255 . 255 . 0


Ok Cancel Apply

GUI Element	Description
Devices	Current device
Host Name ID	Host Name ID - generated by the system and cannot be changed
Alias	User-defined device name containing a maximum of 80 characters
IP Address	Device IP address - can be set only when static mode is selected
Subnet Mask	Subnet mask for the device - can be set only when static mode is selected
Auto	Obtain IP address automatically
DHCP	IP address assigned by DHCP server in router or switch - This is not recommended
Static	IP address is manually configured - if Static is chosen, enter 255.255.0.0 in Subnet Mask

v. Creating Scenes

Scenes are preset configurations of matrix routing or video walls that can be recalled at any time.

- 1 Create a Scene:** Click the **Create** button to create a 2 x 2 scene – the name of the scene can be changed if desired.



Name:


Screen layout

Row: 3

Column: 3

Ok Cancel

Click **OK** and details of the 2 x 2 scene will appear in the window.



Import Export Serial CEC Schedule Information Log Language About

Devices

Search Delete Restore

Alias	Type	Host Name
NHD-210-RX-70B3D5D595AA	RX	NHD-210-RX-70B3D5D595AA
NHD-210-RX-70B3D5D59253	RX	NHD-210-RX-70B3D5D59253
NHD-210-RX-341B228007CF	RX	NHD-210-RX-341B228007CF
NHD-210-RX-341B228007E8	RX	NHD-210-RX-341B228007E8
NHD-210-RX-70B3D5D5956A	RX	NHD-210-RX-70B3D5D5956A
NHD-210-RX-70B3D5D59544	RX	NHD-210-RX-70B3D5D59544
NHD-210-RX-341B228007EE	RX	NHD-210-RX-341B228007EE
NHD-210-RX-70B3D5D59543	RX	NHD-210-RX-70B3D5D59543
NHD-210-RX-341B228007F0	RX	NHD-210-RX-341B228007F0
NHD-200-TX-341B22800E4C	TX	IPE201-341B22800E4C
NHD-200-TX-341B22801004	TX	NHD-200-TX-341B22801004
NHD-200-TX-70B3D5D5A54B	TX	NHD-200-TX-70B3D5D5A54B
NHD-200-TX-341B22800BB1	TX	NHD-200-TX-341B22800BB1

Scenes


nine Create... Modify... Remove Apply

☐ Applied automatically Status: Edit

TX: RX:	TX: RX:	TX: RX:
TX: RX:	TX: RX:	TX: RX:
TX: RX:	TX: RX:	TX: RX:

Drag & Drop the Encoders and Decoders from the left hand menu into the right hand boxes. And Click Apply to test your configuration.

Please note that although an encoder can be used multiple times within a scene, decoders can only be used once.




vi. Sample Video Wall Set Up

Video Wall mode combines multiple display (RX) devices to show a complete video source. Select multiple display devices in the scene setting interface, and combine the cells as follows to configure the Video Wall – see below for 2 x 2 scene as an example:

Preparation

1. One NHD-200-TX Encoder
2. Four NHD-210-RX Decoder
3. A layer 2 Smart Ethernet Switch
4. An HDMI source such as a Blu-ray player
5. Four display panels
6. HDMI cables and Ethernet cables


Hardware Connection



- 1** Connect the Blu-ray player to HDMI IN port of NHD-200-TX with an HDMI cable
- 2** Connect TX to the Switch with Ethernet cables.
- 3** Connect RX1, RX2, RX3, and RX4 to the Switch with Ethernet cables.
- 4** Connect HDMI OUT port of RX1, RX2, RX3, RX4 to the display devices with HDMI cables.
- 5** Power on all devices


vii. Video Wall Configuration

- 1 Link the Devices:** To link RX devices, highlight the first cell and right click > select **Change RX** and select your first RX or drag the them from the left hand menu on to the panels.




Repeat for the remaining Decoders.

- 2 Combine:** Right click any cell > choose **Select All**.




The highlight color will change to indicate all cells have been selected

3 Now right click the cells again and select Combine.



4 Confirm Wall Properties: Clicking Combine brings up the Video Wall Properties screen. Give the Video Wall a Name and set the bezel properties.

vii. Video Wall Properties



GUI Element	Description
Name	Name of the Video Wall
OW	Overall Width of the panel including the bezel.
OH	Overall Height of the panel including the bezel.
VH	Visual Height of the display without the bezel.
VW	Visual Width of the display without the bezel.

! Units are in 0.1mm so if the display measures 56.5cm wide please write 5650.

When you have configured all of your screens you are then ready to export the configuration file to the NHD-000-CTL.

viii. Configuration File Management

Click **Export** to save the configuration file to a specified directory. When exporting please select the Configuration Information for export to the NHD-000-CTL.

Click **Import** to import the configuration file from a directory.

vii. Serial Control

NetworkHD™ 200 Encoders and Decoders can send RS-232 commands to connected devices. To test sending RS-232 commands from one or many devices press the Serial button in the top menu so display the following screen.

The screenshot shows the 'Serial Settings' window. On the left, under 'Devices', there's a 'Filter by Scene' dropdown set to 'nine' and an 'All' checkbox. Below is a table of devices with checkboxes:

Alias	Host Name
<input type="checkbox"/> NHD-200-TX-341B22801004	NHD-200-TX-341B22801004
<input type="checkbox"/> NHD-210-RX-70B3D5D595AA	NHD-210-RX-70B3D5D595AA
<input type="checkbox"/> NHD-210-RX-70B3D5D59253	NHD-210-RX-70B3D5D59253
<input type="checkbox"/> NHD-200-TX-70B3D5D5A54B	NHD-200-TX-70B3D5D5A54B
<input type="checkbox"/> NHD-210-RX-341B228007CF	NHD-210-RX-341B228007CF
<input type="checkbox"/> NHD-200-TX-341B228008B1	NHD-200-TX-341B228008B1
<input type="checkbox"/> NHD-210-RX-341B228007E8	NHD-210-RX-341B228007E8
<input type="checkbox"/> NHD-210-RX-70B3D5D5956A	NHD-210-RX-70B3D5D5956A
<input type="checkbox"/> NHD-210-RX-70B3D5D59544	NHD-210-RX-70B3D5D59544
<input type="checkbox"/> NHD-210-RX-341B228007EE	NHD-210-RX-341B228007EE
<input type="checkbox"/> NHD-210-RX-70B3D5D59543	NHD-210-RX-70B3D5D59543
<input type="checkbox"/> NHD-210-RX-341B228007F0	NHD-210-RX-341B228007F0

On the right, 'Serial Settings' include: Baud Rate (115200), Data Bits (8), Stop Bits (1), and Parity (None). Below is a 'Message' section with a 'Hex Mode' checkbox and a large text input area. At the bottom right are 'Add Carriage-Return Line-Feed' and 'Send' buttons.

Select the Encoders or Decoders to receive the commands in the left hand menu and configure the appropriate serial settings for the receiving device in the top right section.

The required serial string can be entered in the white box ensuring that Hex mode and Carriage return are added if required.

viii. CEC Control

NetworkHD™ 200 decoders are able to turn on and off compatible displays using CEC through the HDMI cable.

Please note that CEC is not always compatible with every display – particularly older models. CEC may also not be enabled by default in your display. Different brands also label CEC control in different ways, please check with your display manufacturer if CEC & One Touch Play is supported.

The screenshot shows the 'CEC Control' window. On the left, under 'Devices', there's a 'Filter by Scene' dropdown set to 'nine' and an 'All' checkbox. Below is a table of devices with checkboxes:

Alias	Host Name
<input type="checkbox"/> NHD-210-RX-70B3D5D595AA	NHD-210-RX-70B3D5D...
<input type="checkbox"/> NHD-210-RX-70B3D5D59253	NHD-210-RX-70B3D5D...
<input type="checkbox"/> NHD-210-RX-341B228007CF	NHD-210-RX-341B2280...
<input type="checkbox"/> NHD-210-RX-341B228007E8	NHD-210-RX-341B2280...
<input type="checkbox"/> NHD-210-RX-70B3D5D5956A	NHD-210-RX-70B3D5D...
<input type="checkbox"/> NHD-210-RX-70B3D5D59544	NHD-210-RX-70B3D5D...
<input type="checkbox"/> NHD-210-RX-341B228007EE	NHD-210-RX-341B2280...
<input type="checkbox"/> NHD-210-RX-70B3D5D59543	NHD-210-RX-70B3D5D...
<input type="checkbox"/> NHD-210-RX-341B228007F0	NHD-210-RX-341B2280...

On the right, there are two buttons: 'One touch play' and 'Stand by'.

To turn on and off your compatible display simply select the decoder in the left hand menu and press the One Touch Play button to turn on and Standby to turn off.

x. Viewing the Encoders Preview Stream

To view the preview stream you require a video decoder capable of supporting CIF formatted material from a Motion-JPEG feed. For best results the renderer should be able to reformat the aspect ratio as CIF formatting can change the aspect ratio of the original content.

WyreStorm highly recommends VLC on all devices for playback.

Simple Stream URL:


In VLC Select Open Network Stream... from the File menu. In the URL bar enter:

http://NHD-200-TX-IP-address/stream

For example:

http://169.254.115.197/stream

Press Open.



To correct the aspect ratio of the feed adjust the “Aspect Ratio” options that are available from the “Video” menu.

ix. Log

The log records the tool operation and device communication information, which can be used for troubleshooting.

```
2014-03-17 00:02:29 - read param name="vw_moninfo_ht", value="vw_moninfo_ht" not defined.
2014-03-17 00:02:29 - Device(EX131-341B22800072) send data succeed [./astparam g vw_moninfo_va
]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_moninfo_ht" not defined/./usr/local/bin # ./astparam g]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_moninfo_ht" not defined/./usr/local/bin # ./astparam g vw_moninfo_va
"vw_moninfo_va" not defined/./usr/local/bin # ]
2014-03-17 00:02:29 - read param name="vw_moninfo_va", value="vw_moninfo_va" not defined.
2014-03-17 00:02:29 - Device(EX131-341B22800072) send data succeed [./astparam g vw_moninfo_vt
]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_moninfo_va" not defined/./usr/local/bin # ./astparam g]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_moninfo_va" not defined/./usr/local/bin # ./astparam g vw_moninfo_vt
"vw_moninfo_vt" not defined/./usr/local/bin # ]
2014-03-17 00:02:29 - read param name="vw_moninfo_vt", value="vw_moninfo_vt" not defined.
2014-03-17 00:02:29 - Device(EX131-341B22800072) send data succeed [./astparam g vw_v_shift
]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_moninfo_vt" not defined/./usr/local/bin # ./astparam g]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_moninfo_vt" not defined/./usr/local/bin # ./astparam g vw_v_shift
"vw_v_shift" not defined/./usr/local/bin # ]
2014-03-17 00:02:29 - read param name="vw_v_shift", value="vw_v_shift" not defined.
2014-03-17 00:02:29 - Device(EX131-341B22800072) send data succeed [cat /sys/devices/platform/display/monitor_info
]
2014-03-17 00:02:29 - Device(EX131-341B22800072) rcv data ["vw_v_shift" not defined/./usr/local/bin # cat /sys/devices
]
2014-03-17 00:02:30 - Device(EX131-341B22800072) rcv data ["vw_v_shift" not defined/./usr/local/bin # cat /sys/devices/platform/display/monitor_info
attached=n
./usr/local/bin # ]
2014-03-17 00:02:30 - Device(EX131-341B22800072) is updated.
2014-03-17 00:02:30 - All devices are updated.
2014-03-17 00:02:30 - Start restoring scene...
2014-03-17 00:02:30 - The scene is restored.
2014-03-17 00:02:30 - The search is complete.
```

13. Additional Information

Further information about NetworkHD™ including system configuration guides and Enado templates can be found at wyrestorm.com

14. NetworkHD™ Control Protocol

The Telnet protocol can be used to send configuration settings, matrix switching and video wall commands to the NetworkHD™ system.

Commands can only be issued to the NHD-000-CTL by IP using **port 23**.

The default IP address of the NHD-000-CTL is **192.168.11.243** – in default configuration commands should be sent to this IP address.

Matrix Switching Control

Command	matrix set TX1 RX1 RX2, TX2 RX3 RX4,...
Return	matrix set: TX1 RX1 RX2, TX2 RX3 RX4,...
Note	Route one or Multiple TX on one or Multiple RX. Each individual TX and its routed RX or RX's compose a record, and should be separated by a commas. Use NULL after a TX and any RX units from this TX will disconnect. Matrix commands cannot be sent when an RX is in video wall mode, first remove the RX from the video wall or use the vw change command E.g.: "matrix set Source1 Screen1 Screen2" sends TX with alias Source1 to RX's with alias' Screen1 & Screen2

Command	matrix get
Return	the connected TX/RX information with below format matrix information: TX1 RX1 TX2 RX3 TX2 RX4
Note	Obtain matrix information. Based on current TX/RX in the network, re-construct the network topology and feedback to the third-party controller.

Activate Scene

Command	scene active scenename
Return	scene scenename active success
Note	Active a certain scene. E.g.: 'scene active VidWall-SettopBox"

Video-Wall

Command	vw add vw-name layout n m TX RX11 RX12 RX13 RX1m RX21 ... RXnm
Return	videowall vw-name layout n m tx rx11 rx12 rx13 rx1m rx21 ... rxnm
Note	Add a video wall layout n rows and m columns, subsequently the RX are automatically assigned positions in the video wall in order. The Parameter RX could be a '0', indicating there is no change to the corresponding RX. E.g.: "vw add wall1 layout 2 2 Source1 Screen1 Screen2 Screen3 Screen4" Note this is a faster way to configure a video wall as it does not require a vw add command previously but is not as flexible as the previous command.

Command	vw change rx tx
Return	videowall config change: rxhostname moved from vw-name and connect to txhostname
Note	Set RX to full-screen display of TX. Used for matrix switching in configurations that use video wall mode or to remove an individual RX from the video wall and display a different or identical TX. E.g.: "vw change Screen1 Source4"

Command	vw change vw-name tx-name
Return	videowall vw-name tx connect to txhostname
Note	Set all RX in the video wall to display another TX. E.g.: "vw change wall1 input1"

Command	vw bezelgap vw-name ow oh vw vh
Return	videowall vw-name's bezelgap: xx xx xx xx
Note	Set the size of TV frame (video edge) to correct for large bezel screens. units are in mm (0.1cm). ow & oh = overall width & height of display including the bezel, vw & vh = screen width and height. E.g.: "vw bezelgap wall1 16100 9100 16000 9000"

Command	vw pictureparam vw-name h-shift v-shift h-scale v-scale tearing-delay rx1 rx2 rx3 ...
Return	set videowall vw-name's pictureparam: xx xx xx xx xx to rx1 rx2 rx3 ...
Note	Configure the rx1/rx2/rx3 ... image shift. 1 unit = 8 pixels, a negative number indicates to move left or up). Scale units = 1 Row or Columns / tearing delay units: μ s, values between 10000~16000). If a parameter is 0 it will not be changed. E.g.: "vw pictureparam wall1 2 1 3 3 12500 Screen3 Screen4" will shift the image on screen 3 and 4 16 pixels down, 8 pixels right, whilst over-scaling by 3 rows and 3 columns and setting the tearing delay to 12500 μ s.

Command	vw get
Return	video wall information: vw-name1 TX1 row-number1 RX11 RX12.. row-number2 RX21RX22 vw-name2 TX2 row-number1 RX11 RX12... ...
Note	Obtain video wall information and feedback video wall configurations.

Serial

Pass-through the serial commands.

Command	serial -b param -r {on off} -h {on off} "command-string" hostname1 hostname2 ...
Return	serial command received: <cr> serial -b param -r {on off} -h {on off} "command-string" hostname1 hostname2 ...
Note	Configure devices hostname1, hostname2 to pass a serial command. Command-strings cannot contain "&". -b param, configure the RS-232 format of the peripheral, Baud rate, Data bits, Parity and Stop bits. E.g.: -b 115200-8n1. -r {on off}, to turn on & off Carriage Return following the command-string. -h {on off}, to turn on & off hex. hostname1 hostname2 ..., indicates the destination, could be multiple. E.g.: "serial -b 9600-8n1 -r on -h off "PWR01" Screen1 Screen2 Screen3" Sends the ASCII command "PWR01" to Screens 1, 2 & 3 with a carriage return at 9600 baud – 8 data bits, No parity, 1 Stop bit.

CEC

Pass-through the CEC commands.


Command	config set device cec standby RX1 RX2 ...
Return	config set device cec standby hostname1 hostname2 ...
Note	Set the display which is connected to RX device to standby mode. The display must support CEC control. E.g.: "config set device cec standby Screen1"

Command	config set device cec onetouchplay RX1 RX2 ...
Return	config set device cec onetouchplay hostname1 hostname2 ...
Note	Turn on the display which is connected to the RX device. The display must support CEC control. E.g.: "config set device cec onetouchplay Screen1""

15. Troubleshooting

1) If NetworkHD™ Software Console cannot find any devices on the network - If following the network settings advice in sections 10 through 14 above does not yield any devices, check your Windows Firewall settings. Using Windows 7 as an example (Other versions of Windows may differ):

- Click **Start** menu, go to **Control Panel > System and Security > Windows Firewall > Allowed Programs**, highlight **NetworkHDconsole.exe**, check **Home/Work (Private)** and **Public**.



- Check the IP address and subnet mask of the PC. The network segment for IP address is **169.254.x.x** and the subnet mask is **255.255.0.0**, the PC and encoder/decoder should be in the same network segment. **(See section 11.)**

- Check the settings of the switch match those in the Switch Configuration Guides available from **wyrestorm.com**

- Ensure that the Bonjour SDK software has been installed on the machine you are using - the installer is available in the Network-HD™ software console installation file.

2) If you are unable to access the web management UI

- Check the IP address of your computer. The default IP address of the IP Control Box is 192.168.11.243, so the IP address of the computer should be 192.168.11.xxx.
- Check the Web browser. We recommend you use Firefox, Opera, Safari Internet Explorer 11 or Chrome. If the problem persists, try to upgrade you browser to the latest version.
- Perform a reset on the NHD-000-CTL by holding down the reset button on the front of the device.

3) If no devices appear in the Matrix or TX/RX Settings page...

- Ensure the devices are powered up and connected to the same network
- Ensure that the network settings in the router are correct for those set in the RX/TX units
- Refresh the browser
- Reboot all system components including the NHD-000-CTL
- Perform a reset on the NHD-000-CTL by holding down the reset button on the front of the device

4) If you cannot set a device Alias...

A device may have previously been connected to the NHD-000-CTL with that Alias.

You will need to factory reset the CTL for it to lose that alias, be aware of alias conflicts if that other device is still connected but powered down.

5) If the decoder device continuously reboots...

The decoder is set to DHCP but it cannot find a DHCP server. You must connect the unit to a DHCP server so that it can finishing initialising. You will then be able to change the IP settings.

6) If you are unable to connect to the web interface of the NHD-000-CTL:

- Ensure that the Ethernet switch is configured as per the switch configuration guides at wyrestorm.com (You may need to disconnect all encoder devices from the switch in order to regain network connection.)
- Ensure that your computer IP address is in the same subnet as the NHD-000-CTL **(by default 192.168.11.xxx)**

7) If you do not see an image on the display:

- Screen message shows “waiting for Encoders” or “waiting for video source” - the encoders is offline or the source has turned off/entered standby. Check TX or source device is powered and switched on
- Screen is completely blank - check display is on and correct input is selected, ensure the RX is powered and the lights are stable on the front. Replace the HDMI cable for a cable tested fully working
- Only part of the Image is displayed - the device is in “video wall mode”. Send a command to exit the device from video.

Note: be aware of alias conflicts if devices are still connected but powered down.

8) If the IP address settings of the NHD-200-TX & RX devices are not taking please reboot them after making the settings.

9) If the video or audio is distorted please reboot both the source device and the encoders.

16. FAQ

What compression technology is utilised in NetworkHD™?

NetworkHD™ utilises high quality H.264 compression algorithm to produce very high quality images that are indistinguishable from the original at normal viewing distances.

What resolution audio & Video does NetworkHD™?

NetworkHD™ supports up to full HD 1080P HDMI video inputs and high quality stereo audio.

How many Decoder & Encoder units can I use in a NetworkHD™ system?

NetworkHD™ is a highly scalable system tested with up to 1000 encoder/decoder devices.

17. Maintenance

Clean this unit with a soft, dry cloth only. Never use alcohol, paint thinner or other harsh chemicals.

18. Provided Service

1. Damage requiring service: This unit should be serviced by a qualified service personnel if:

- The power supply or AC adaptor has been damaged.
- Objects or liquid have gotten into the unit.
- The unit has been exposed to rain.
- The unit does not operate normally or exhibits a marked change in performance.
- The unit has been dropped or the cabinet damaged.

2. Servicing Personnel: Do not attempt to service the unit beyond that described in these operating instructions. Refer all other servicing to authorised servicing personnel.

3. Replacement Parts: When parts need replacing, ensure parts approved by the manufacturer are used – either those specified by the manufacturer or parts possessing the same characteristics as the original parts. Be aware – unauthorised substitutes may result in fire, electric shock, or other hazards and will invalidate your warranty.

4. Safety Check: After repairs or service, ask the service personnel to perform safety checks to confirm the unit is in proper working condition. When shipping the unit, carefully pack and send it prepaid, with adequate insurance and preferably in the original packaging. Please include a document or letter detailing the reason for return and include a daytime telephone number and/or email address where you can be contacted.

19. Mail-in-service

When shipping the unit, carefully pack and send it prepaid, with adequate insurance and preferably in the original packaging. Please include a document or letter detailing the reason for return and include a daytime telephone number and/or email address where you can be contacted.

If repair is required during the limited warranty period, the purchaser will be required to provide a sales receipt or other proof of purchase, indicating date and location of purchase as well as the price paid for the product. The customer will be charged for the repair of any unit received unless such information is provided.

20. Warranty

Should you feel your product does not function adequately due to defects in materials or workmanship, we (referred to as “the warrantor”) will, for the length of the period indicated below (starting from the original date of purchase) either:

- a) Repair the product with new or refurbished parts.
- or
- b) Replace it with a new or refurbished product.

Limited warranty period:

All Wyrestorm products are covered by a 3 year PARTS and LABOUR warranty. During this period there will be no charge for unit repair, replacement of unit components or replacement of product if necessary.

The decision to repair or replace will be made by the warrantor. The purchaser must mail-in the product during the warranty period. This limited warranty only covers the product purchased as new and is extended to the original purchaser only. It is non-transferable to subsequent owners, even during the warranty period.

A purchase receipt or other proof of original purchase date is required for the limited warranty service.

21. Warranty Limits & Exclusions

1. This Limited Warranty ONLY COVERS failures due to defects in materials or workmanship and DOES NOT COVER normal wear and tear or cosmetic damage.

The limited warranty also DOES NOT COVER damage that occurs in shipment or failures caused by products not supplied by the warrantor, failures resulting from accident, misuse, abuse, neglect, mishandling, misapplication, alteration, incorrect installation, set-up adjustment, implementation of/to consumer controls, improper maintenance, power line surge, lightening damage, modification, service by anyone other than a manufacturer-approved service centre or factory-authorised personnel, or damage attributable to acts of God.

2. There are no express warranties except as listed under “limited warranty coverage.” The warrantor is not liable for incidental or consequential damage resulting from the use of this product or arising out of any breach of this warranty.

For example: damages for lost time, the cost of having a person/persons remove or re-install previously installed equipment, travel to and from service location, loss of or damage to media, images, data or other recorded/stored.

22. Disclaimer

WYRESTORM PUBLICATION DISCLAIMER

The material contained in this document consists of information that is the sole property of WyreStorm. This document is intended to provide information to allow interfacing to the relevant WyreStorm equipment by third party products.

WYRESTORM IS NOT RESPONSIBLE FOR MALFUNCTIONS AND/OR THE IN-OPERABILITY WHICH MAY BE CAUSED BY THE APPLICATION OF THIS INFORMATION, WHETHER EXPECTED OR NOT.

WyreStorm reserves the right to change software, control codes and specifications without notice.

WyreStorm will not be liable for any use of this information or any changes it may make to those products. The use of this information constitutes an agreement by the user to these limitations and exclusions.

23. Installation Reference Logs

Encoder

	Zone	Group	Screen No.	Display Type	TX Mac Address	Tested Cable Length	Switch No.	Port No.	Power Light on TX	Power to Source	Picture on Test Monitor	Highest Pos. Res. Set on Source	Auto Power off Disabled	Alias Set for Encoder	Visible on CTL
1															
2															
3															
4															
5															
6															
7															
8															
9															
10															
11															
12															
13															
14															
15															
16															

17																	
18																	
19																	
20																	
21																	
22																	
23																	
24																	
25																	

Decoder

	Zone	Group	Screen No.	Display Type	RX Mac Address	Tested Cable Length	Switch No.	Port No.	Power Light on RX	Power to Display	Picture on Test Monitor	Overscan Disabled on Screen	Auto Power off Disabled	CEC Enabled	Alias Set for Decoder	Visible on CTL
1																
2																
3																
4																
5																
6																
7																
8																
9																
10																
11																
12																
13																
14																
15																
16																
17																
18																

19																	
20																	
21																	
22																	
23																	
24																	
25																	
26																	
27																	
28																	
29																	
30																	
31																	
32																	
33																	
34																	
35																	
36																	
37																	
38																	
39																	
40																	
41																	
42																	
43																	
44																	
45																	
46																	
47																	
48																	
49																	
50																	



wyrestorm.com

WyreStorm Offices

North America Office: Tech Valley Park, 23 Wood Road, Round Lake, NY 12151 USA

Tel: +1 518-289-1293

EMEA Office: Unit 22, Ergo Business Park, Swindon, Wiltshire, SN3 3JW, UK

Tel: +44 (0) 1793 230 343

WyreStorm Technical Support

US: +1 844-280-WYRE (9973)

UK:- +44 (0) 1793 230 343

Email: support@wyrestorm.com

WyreStorm Technologies reserve the right to change physical appearance or technical specification of this product at any time.

Visit wyrestorm.com for the latest information on products..