


TD-30

DRUM SOUND MODULE

Data List



Roland

Preset Drum Kit List

No.	Name	Pad pattern
1	Studio	
2	LA Metal	
3	Swingin'	
4	Burnin'	
5	Birch	
6	Nashville	
7	LoudRock	
8	JJ's DnB	
9	Djembe	
10	Stage	
11	RockMaster	
12	LoudJazz	
13	Overhead	
14	Looooose	
15	Fusion	
16	Room	
17	[RadioMIX]	
18	R&B	
19	Brushes	
20	Vision	LOOP, TAP
21	AstroNote	1SHOT
22	acidfunk	
23	PunkRock	
24	OpenMaple	
25	70s Rock	
26	DrySound	
27	Flat&Shallow	
28	Rvs!Trashy	
29	melodious	TAP
30	HARD n'BASS	TAP
31	BazzKicker	
32	FatPressed	
33	DrumnDubStep	
34	ReMix-ulator	
35	Acoutronic	
36	HipHop	
37	90sHouse	
38	D-N-B	LOOP
39	SuperLoop	TAP
40	>>process>>>	

No.	Name	Pad pattern
41	RockGig	
42	Hard BeBop	
43	Rock Solid	
44	2nd Line	
45	ROBO	TAP
46	SATURATED	
47	piccolo	
48	FAT	
49	BigHall	
50	CoolGig	LOOP
51	JazzSes	LOOP
52	7/4 Beat	LOOP
53	:neotype:	1SHOT, TAP
54	FLA>n<GER	1SHOT, TAP
55	CustomWood	
56	50s King	
57	BluesRock	
58	2HH House	
59	TechFusion	
60	BeBop	
61	Crossover	
62	Skanky	
63	RoundBdge	
64	Metal\Core	
65	JazzCombo	
66	Spark!	
67	80sMachine	
68	=cosmic=	
69	1985	
70	TR-808	
71	TR-909	
72	LatinDrums	
73	Latin	
74	Brazil	
75	Cajon	
76	African	
77	Ka-Rimba	
78	Tabla	TAP
79	Asian	
80	Orchestra	TAP

Copyright © 2012 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Roland and V-Drums are either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.

Restoring the factory-set drum kits

Restoring a single drum kit to the factory settings

You can use the Copy function to restore a single drum kit to its factory settings.

1. Hold down the [SHIFT] button and press the [USB MEM] button.

[USB MEM] button will light, and the COPY A screen will appear.



2. Press the [F1] (KIT) button.



3. Press the [F2] (PRESET) button.
4. Use the cursor buttons, [-] [+] buttons, and dial to specify the "drum kit (Preset)" that you want to restore, and the "copy-destination (User)" into which you want to write the data.
5. Press the [F5] (COPY) button.
6. Press the [F5] (EXECUTE) button.

The drum kit will be copied.

Restoring all drum kits and settings to their factory-set state

Refer to "Restoring the factory settings" in the owner's manual for the TD-30.

About "User Kits"

Drum kit numbers 81–100 are "User Kits."

In the "User Kits," settings such as pad volume are set to typical values. You can use these when you want to create a kit from scratch.

About the pad pattern types

Pad pattern	Explanation
LOOP	When you strike a pad to which this pattern is assigned, a backing pattern will play as a loop; the pattern will stop when you strike the same pad once again (Loop Pattern).
1SHOT	When you strike a pad to which this pattern is assigned, a pre-assigned pattern will play only once (One-Shot Pattern).
TAP	Each time you strike a pad to which this pattern is assigned, a chord or melody will play, one note at a time (Tap Pattern).

Drum Instrument List

No.	Name	Remarks
KICK A		
1	22"HallCut K	
2	22"StdBrch K	
3	22"PwrBrch K	
4	22"Fiber K	
5	22"D-Maple K	
6	22"ClscMpl K	
7	22"CstmSQ K	
8	22"MapleBz K	
9	22"LooseLo K	
10	22"OpenMpl K	
11	22"PwrAmb K	
KICK B		
12	22"BirchLo K	
13	22"BirchHi K	
14	23"D-Maple K	
15	22"NCMaple K	
16	22"LwgVntg K	
17	22"RokVntg K	
18	22"PKMaple K	
19	22"SnrVntg K	
20	24"VLite K	
21	22"Premium K	
22	22"BrchWet K	
23	22"GT Vntg K	
24	22"LooseHd K	
25	20"TightHd K	
26	20"GT Open K	
27	20"BigBand K	
28	18"Combo K	
29	18"BeBopLo K	
30	18"BeBopHi K	
31	Ambience K	
KICK C		
32	22"Birch K	
33	22"Solid K	
34	22"StdMple K	
35	22"Maple K	
36	24"Carbon K	
37	22"CbnMple K	
38	22"GT K	
39	22"TitanHp K	
40	22"Mahogny K	
41	20"Lite K	
42	22"RoseWd K	
43	22"Oak K	
44	Recording1 K	

No.	Name	Remarks
45	Recording2 K	
46	Universal K	
47	BigOpen K	
48	JazzCombo1 K	
49	JazzCombo2 K	
50	Cannon K	
51	Roto K	
52	Booth K	
53	Ballad K	
54	Swing K	
55	Heavy K	
56	Can K	
57	Fusion K	
58	Latin K	
59	Meat K	
60	Pillow K	
61	DryMed K	
62	Dry K	
63	DrySolid K	
64	Reso K	
65	Raw K	
66	Vintage K	
67	OldMaple K	
68	Hard K	
69	BigLow K	
70	Hybrid K	
71	Gabba1 K	
72	Gabba2 K	
73	Gabba3 K	
KICK PROCESSED		
74	MonoStomp K	
75	CloseDoor K	
76	HardAttack K	
77	BoomLo K	
78	Boxer K	
79	BoxerHi K	
80	Slap K	
81	Tight1 K	
82	Tight2 K	
83	Tight3 K	
84	Tight4 K	
85	Tight5 K	
86	Tight6 K	
87	Solid1 K	
88	Solid2 K	
89	Solid3 K	
90	Wild K	

No.	Name	Remarks
91	Mondo K	
92	Reverb K	
93	Distorted K	
94	BreakBeats K	
95	Woofer K	
96	FX Stomp K	
97	FX Chest K	
98	FX Handle K	
99	FX Door K	
100	Cartoon K	
101	Chicken K	
102	Jive K	
103	RB K	
104	Layered K	
105	Lazy K	
106	HardLow K	
107	Alley K	
108	DaFloor K	
109	Croak K	
110	Plastic K	
111	Trip K	
112	Gokigen K	
113	FX-Wah K	
114	Lo-Fi K	
KICK ELECTRONIC		
115	EleLo K	
116	Typewriter K	
117	HiJumper K	
118	LoJumper K	
119	Dancer K	
120	Wobbly K	
121	Bounce K	
122	FastBender K	
123	ClscElec1 K	
124	ClscElec2 K	
125	ClscElec3 K	
126	ClscElec4 K	
127	ClscElec5 K	
128	ClscElec6 K	
129	ClscElec7 K	
130	ClscElec8 K	
131	ClscElec9 K	
132	TR808 K	
133	808Attack K	
134	808Low K	
135	808Long K	
136	TR909 K	

Drum Instrument List

No.	Name	Remarks
137	909Power K	
138	909Low K	
139	909Low2 K	
140	Cosmic K	
141	Hi-Q K	
142	Analog1 K	
143	Analog2 K	
144	Analog3 K	
145	AnalogQ1 K	
146	AnalogQ2 K	
147	AnalogQ3 K	
148	Synthy K	
149	Filter1 K	
150	Filter2 K	
151	Filter3 K	
152	Filter4 K	
153	Jungle K	
154	FX Elec1 K	
155	FX Elec2 K	
156	FX Elec3 K	
157	FX Elec4 K	
SNARE A		
158	Stainless S	*P *X
159	Stainless SR	*P *X
160	40s Maple S	*P *X
161	40s Maple SR	*P *X
162	SuprSteel S	*P *X
163	SuprSteel SR	*P *X
164	Mahogany S	*P *X
165	Mahogany SR	*P *X
166	SldMaple S	*P *X
167	SldMaple SR	*P *X
168	TightBrch S	*P *X
169	TightBrch SR	*P *X
170	PowerAmb S	*P *X
171	PowerAmb SR	*P *X
SNARE B		
172	CustmWood S	*P
173	CustmWood SR	*P *X
174	80s Metal S	*P
175	80s Metal SR	*P *X
176	Bronze S	*P
177	Bronze SR	*P *X
178	CraftStl S	*P
179	CraftStl SR	*P *X
180	OpenBrass S	*P
181	OpenBrass SR	*P *X

No.	Name	Remarks
182	50s King S	*P
183	50s King SR	*P *X
184	GT Maple S	*P
185	GT Maple SR	*P *X
186	Piccolo S	*P
187	Piccolo SR	*P *X
188	12"Cmpact S	
189	12"Cmpact SR	*X
190	10"Cmpact S	
191	10"Cmpact SR	*X
192	Skanky2 S	*P
193	Skanky2 SR	*P *X
194	StlPhonic S	*P
195	StlPhonic SR	*P *X
SNARE C		
196	RoundBdge S	*P
197	RoundBdge SR	*P *X
198	CoolyMple S	*P
199	CoolyMple SR	*P *X
200	70s Metal S	*P
201	70s Metal SR	*P *X
202	WoodBrass S	*P
203	WoodBrass SR	*P *X
204	13"Hole S	*P
205	13"Hole SR	*P *X
206	Aluminum S	*P
207	Aluminum SR	*P *X
208	Titanium S	*P
209	Titanium SR	*P *X
210	Skanky S	*P
211	Skanky SR	*P *X
212	30s Maple S	*P
213	30s Maple SR	*P *X
214	BrassPico S	*P
215	BrassPico SR	*P *X
SNARE D		
216	50sKingMt S	
217	50sKingMt SR	*X
218	WhiteAsh S	
219	WhiteAsh SR	*X
220	Popcorn S	
221	Popcorn SR	*X
222	Booth S	
223	Booth SR	*X
224	Studio S	
225	Studio SR	*X
226	Ballad S	

No.	Name	Remarks
227	Ballad SR	*X
228	Swing S	*P
229	Swing SR	*X
230	Street S	*P *X
231	Lite S	*P *X
232	LA Fat S	*X
233	Ring S	*X
234	Whack S	*X
235	Impulse S	*X
236	Cruddy1 S	*X
237	Cruddy2 S	*X
238	HotRod S	
239	HotRod SR	*X
SNARE BRUSH		
240	Brush1 S	*B
241	Brush1 SR	*X
242	Brush2 S	*B
243	Brush2 SR	*X
SNARE XSTICK		
244	Stnless XStk	
245	40sMapl XStk	
246	SupraSt XStk	
247	Mahogny XStk	
248	SldMapl XStk	
249	Tight XStk	
250	PwrAmb XStk	
251	GateRev XStk	
252	Wood XStk	
253	Steel XStk	
254	Brass XStk	
255	80sMtl XStk	
256	50sKing XStk	
257	WhtAsh XStk	
258	Light XStk	
259	Lo-Fi XStk	
260	Round XStk	
261	Cooly XStk	
262	70s XStk	
263	WoodBr XStk	
264	13" XStk	
265	Alumi XStk	
266	Titan XStk	
267	Skanky XStk	
268	30s XStk	
269	Reggae XStk	
270	Ballad XStk	
271	Studio XStk	

Drum Instrument List

No.	Name	Remarks
272	Swing XStk	
273	Hard XStk	
274	Maple XStk	
275	RimClick1	
276	RimClick2	
SNARE PROCESSED		
277	PrcsStnls S	*X
278	PrcsStnls SR	*X
279	PrcsBirch S	*X
280	PrcsBirch SR	*X
281	PrcsSldMp S	*X
282	PrcsSldMp SR	*X
283	PrcsSteel S	*X
284	PrcsSteel SR	*X
285	Slapper S	*X
286	Clapper S	*X
287	PowerDrop S	*X
288	HardShort S	*X
289	LongNoiz S	*X
290	PrcsWood S	*X
291	PrcsWood SR	*X
292	PrcsMetal S	*X
293	PrcsMetal SR	*X
294	PrcsElec1 S	*X
295	PrcsElec1 SR	*X
296	PrcsElec2 S	*X
297	PrcsElec2 SR	*X
298	PrcsXStik S	*X
299	PrcsNoise S	*X
300	DynaFilterS	*X
301	ClscFat1 S	*X
302	ClscFat1 SR	*X
303	ClscFat2 S	*X
304	ClscFat2 SR	*X
305	SoundFX1 S	*X
306	SoundFX2 S	*X
307	SoundFX3 S	*X
308	SoundFX4 S	*X
309	SoundFX5 S	*X
310	Distorted1S	*X
311	Distorted2S	*X
312	Basis S	*X
313	Chunk S	*X
314	ClapTail S	*X
315	ClubDry S	*X
316	Dump S	*X
317	HopRim1 S	*X

No.	Name	Remarks
318	HopRim2 S	*X
319	HopRim3 S	*X
320	LzrGate S	*X
321	Pick S	*X
322	Planet S	*X
323	RB S	*X
324	2Step S	*X
325	Lo-Fi S	*X
SNARE ELECTRONIC		
326	ClscElec1 S	*X
327	ClscElec2 S	*X
328	ClscElec3 S	*X
329	ClscElec4 S	*X
330	ClscElec5 S	*X
331	ClscElec6 S	*X
332	ClscElec7 S	*X
333	ClscElec8 S	*X
334	ClscElec9 S	*X
335	TR808 S	
336	TR808 SR	*X
337	808Power S	*X
338	808Power SR	*X
339	TR909 S	
340	TR909 SR	*X
341	909Power S	*X
342	909Power SR	*X
343	909Dist S	*X
344	909Reverb S	*X
TOM A		
345	10"Custm T1	
346	10"Custm T1R	*P
347	12"Custm T2	
348	12"Custm T2R	*P
349	14"Custm T3	
350	14"Custm T3R	*P
351	16"Custm T4	
352	16"Custm T4R	*P
353	18"Custm T5	
354	18"Custm T5R	*P
355	10"D-Mpl T1	
356	10"D-Mpl T1R	*P
357	12"D-Mpl T2	
358	12"D-Mpl T2R	*P
359	13"D-Mpl T3	
360	13"D-Mpl T3R	*P
361	16"D-Mpl T4	
362	16"D-Mpl T4R	*P

No.	Name	Remarks
363	18"D-Mpl T5	
364	18"D-Mpl T5R	*P
365	12"Loose T1	
366	12"Loose T1R	*P
367	13"Loose T2	
368	13"Loose T2R	*P
369	16"Loose T3	
370	16"Loose T3R	*P
371	18"Loose T4	
372	18"Loose T4R	*P
373	10"OldJz T1	
374	10"OldJz T1R	*P
375	12"OldJz T2	
376	12"OldJz T2R	*P
377	13"OldJz T3	
378	13"OldJz T3R	*P
379	16"OldJz T4	
380	16"OldJz T4R	*P
TOM B		
381	8"NCMpl T1	
382	8"NCMpl T1R	*P
383	10"NCMpl T2	
384	10"NCMpl T2R	*P
385	12"NCMpl T3	
386	12"NCMpl T3R	*P
387	14"NCMpl T4	
388	14"NCMpl T4R	*P
389	16"NCMpl T5	
390	16"NCMpl T5R	*P
391	8"PKJaz T1	
392	8"PKJaz T1R	*P
393	10"PKJaz T2	
394	10"PKJaz T2R	*P
395	12"PKJaz T3	
396	12"PKJaz T3R	*P
397	13"PKJaz T4	
398	13"PKJaz T4R	*P
399	16"PKJaz T5	
400	16"PKJaz T5R	*P
401	10"Rock T1	
402	10"Rock T1R	*P
403	12"Rock T2	
404	12"Rock T2R	*P
405	14"Rock T3	
406	14"Rock T3R	*P
407	16"Rock T4	
408	16"Rock T4R	*P

Drum Instrument List

No.	Name	Remarks
409	18"Rock T5	
410	18"Rock T5R	*P
411	8"Pop T1	
412	8"Pop T1R	*P
413	10"Pop T2	
414	10"Pop T2R	*P
415	12"Pop T3	
416	12"Pop T3R	*P
417	13"Pop T4	
418	13"Pop T4R	*P
419	16"Pop T5	
420	16"Pop T5R	*P
421	8"Antiq T1	
422	8"Antiq T1R	*P
423	10"Antiq T2	
424	10"Antiq T2R	*P
425	12"Antiq T3	
426	12"Antiq T3R	*P
427	13"Antiq T4	
428	13"Antiq T4R	*P
429	16"Antiq T5	
430	16"Antiq T5R	*P
TOM C		
431	12"Birch T1	
432	12"Birch T1R	*P
433	13"Birch T2	
434	13"Birch T2R	*P
435	16"Birch T3	
436	16"Birch T3R	*P
437	18"Birch T4	
438	18"Birch T4R	*P
439	12"GT T1	
440	12"GT T1R	*P
441	13"GT T2	
442	13"GT T2R	*P
443	16"GT T3	
444	16"GT T3R	*P
445	18"GT T4	
446	18"GT T4R	*P
447	10"Univ T1	
448	10"Univ T1R	*P
449	12"Univ T2	
450	12"Univ T2R	*P
451	14"Univ T3	
452	14"Univ T3R	*P
453	16"Univ T4	
454	16"Univ T4R	*P

No.	Name	Remarks
455	12"Clasc T1	
456	12"Clasc T1R	*P
457	13"Clasc T2	
458	13"Clasc T2R	*P
459	16"Clasc T3	
460	16"Clasc T3R	*P
461	18"Clasc T4	
462	18"Clasc T4R	*P
463	12"Fiber T1	
464	12"Fiber T1R	*P
465	14"Fiber T2	
466	14"Fiber T2R	*P
467	16"Fiber T3	
468	16"Fiber T3R	*P
469	18"Fiber T4	
470	18"Fiber T4R	*P
471	12"Maple T1	
472	12"Maple T1R	*P
473	14"Maple T2	
474	14"Maple T2R	*P
475	16"Maple T3	
476	16"Maple T3R	*P
477	18"Maple T4	
478	18"Maple T4R	*P
479	12"Oak T1	
480	12"Oak T1R	*P
481	14"Oak T2	
482	14"Oak T2R	*P
483	16"Oak T3	
484	16"Oak T3R	*P
485	18"Oak T4	
486	18"Oak T4R	*P
487	8"Roto T1	
488	8"Roto T1R	
489	10"Roto T2	
490	10"Roto T2R	
491	12"Roto T3	
492	12"Roto T3R	
493	14"Roto T4	
494	14"Roto T4R	
495	16"Roto T5	
496	16"Roto T6	
497	18"Roto T7	
498	18"Roto T8	
499	18"RotoExLo1	
500	18"RotoExLo2	
501	Ballad T1	

No.	Name	Remarks
502	Ballad T2	
503	Ballad T3	
504	Ballad T4	
505	Swing T1	
506	Swing T2	
507	Swing T3	
508	Swing T4	
509	Pop1 T1	
510	Pop1 T2	
511	Pop1 T3	
512	Pop1 T4	
513	Pop2 T1	
514	Pop2 T2	
515	Pop2 T3	
516	Pop2 T4	
517	Round T1	
518	Round T2	
519	Round T3	
520	Round T4	
521	80s Dry T1	
522	80s Dry T2	
523	80s Dry T3	
524	80s Dry T4	
525	90s Big T1	
526	90s Big T2	
527	90s Big T3	
528	90s Big T4	
529	90s Power T1	
530	90s Power T2	
531	90s Power T3	
532	90s Power T4	
533	OctaTom C Hi	
534	OctaTom B	
535	OctaTom A	
536	OctaTom G	
537	OctaTom F	
538	OctaTom E	
539	OctaTom D	
540	OctaTom C	
541	Mallet T1	
542	Mallet T2	
543	Mallet T3	
544	Mallet T4	
545	Brush T1	
546	Brush T2	
547	Brush T3	
548	Brush T4	

Drum Instrument List

No.	Name	Remarks
TOM ELECTRONIC		
549	ClscElec1 T1	
550	ClscElec1 T2	
551	ClscElec1 T3	
552	ClscElec1 T4	
553	ClscElec2 T1	
554	ClscElec2 T2	
555	ClscElec2 T3	
556	ClscElec2 T4	
557	ClscElec3 T1	
558	ClscElec3 T2	
559	ClscElec3 T3	
560	ClscElec3 T4	
561	ClscElec4 T1	
562	ClscElec4 T2	
563	ClscElec4 T3	
564	ClscElec4 T4	
565	ClscElec5 T1	
566	ClscElec5 T2	
567	ClscElec5 T3	
568	ClscElec5 T4	
569	ClscElec6 T1	
570	ClscElec6 T2	
571	ClscElec6 T3	
572	ClscElec6 T4	
573	ClscElec7 T1	
574	ClscElec7 T2	
575	ClscElec7 T3	
576	ClscElec7 T4	
577	ClscElec8 T1	
578	ClscElec8 T2	
579	ClscElec8 T3	
580	ClscElec8 T4	
581	ClscElec9 T1	
582	ClscElec9 T2	
583	ClscElec9 T3	
584	ClscElec9 T4	
585	ElecNoiz T1	
586	ElecNoiz T2	
587	ElecNoiz T3	
588	ElecNoiz T4	
589	TR808 T1	
590	TR808 T2	
591	TR808 T3	
592	TR808 T4	
593	TR909 T1	
594	TR909 T2	

No.	Name	Remarks
595	TR909 T3	
596	TR909 T4	
HI-HAT		
597	14"Custom HB	
598	14"Custom HE	
599	14"SessionHB	
600	14"SessionHE	
601	14"CstmDK HB	
602	14"CstmDK HE	
603	14"Medium HB	
604	14"Medium HE	
605	13"KZComb HB	
606	13"KZComb HE	
607	13"P-Crsp HB	
608	13"P-Crsp HE	
609	14"P-Hat HB	
610	14"P-Hat HE	
611	13"Hatz HB	
612	13"Hatz HE	
613	14"Hatz HB	
614	14"Hatz HE	
615	14"Dark HB	
616	14"Dark HE	
617	14"Edge HB	
618	14"Edge HE	
619	Brush HH	
620	Triangle HH	
621	HandCym HH	
622	CR78 HH	
623	TR808 HH	
624	TR909 HH	
625	Tekno HH	
626	Elec HH	
HI-HAT PROCESSED		
627	LoFi 909 HB	
628	LoFi 909 HE	
629	Distorted HB	
630	Distorted HE	
631	Lo-Fi HH	
632	808Chick HH	
633	909Power HH	
634	Impulse HH	
635	Super-Q HH	
636	DistJingleHH	
637	MtlCrasherHH	
638	Jingle HH	
639	Beads HH	

No.	Name	Remarks
640	Ratchet HH	
CRASH A		
641	16"CustmCrBw	
642	16"CustmCrEg	
643	18"CustmCrBw	
644	18"CustmCrEg	
645	16"StdioCrBw	
646	16"StdioCrEg	
647	16"DkThnCrBw	
648	16"DkThnCrEg	
649	18"DkThnCrBw	
650	18"DkThnCrEg	
CRASH B		
651	15"PaperCrBw	
652	15"PaperCrEg	
653	16"PoP CrBw	
654	16"PoP CrEg	
655	18"PoP CrBw	
656	18"PoP CrEg	
657	17"DarK CrBw	
658	17"DarK CrEg	
659	18"DarK CrBw	
660	18"DarK CrEg	
661	18"JazZ CrBw	
662	18"JazZ CrEg	
663	16"DarK CrBw	
664	16"DarK CrEg	
665	16"Thin CrBw	
666	16"Thin CrEg	
667	16"PaperCrBw	
668	16"PaperCrEg	
669	16"FsPwrCrBw	
670	16"FsPwrCrEg	
671	18"PowerCrBw	
672	18"PowerCrEg	
673	18"Med CrBw	
674	18"Med CrEg	
675	19"NY CrBw	
676	19"NY CrEg	
677	18"Fast CrBw	
678	18"Fast CrEg	
679	18"Fast CrBl	
680	Brush CrBw	
681	Brush CrEg	
682	Mallet Cr	
SPLASH		
683	4"Paper SpBw	

Drum Instrument List

No.	Name	Remarks
684	4"Paper SpEg	
685	6"Splaz SpBw	
686	6"Splaz SpEg	
687	6"SplazhSpBw	
688	6"SplazhSpEg	
689	8"Thin SpBw	
690	8"Thin SpEg	
691	8"Bell SpBw	
692	8"Bell SpEg	
693	8"Open SpBw	
694	8"Open SpEg	
695	10"UF SpBw	
696	10"UF SpEg	
697	10"Med SpBw	
698	10"Med SpEg	
699	10"CustmSpBw	
700	10"CustmSpEg	
CHINA		
701	10"ChinaSpBw	
702	10"ChinaSpEg	
703	12"PgyBackBw	
704	12"PgyBackEg	
705	13"Latin Bw	
706	13"Latin Eg	
707	14"Trash Bw	
708	14"Trash Eg	
709	16"Swish Bw	
710	16"Swish Eg	
711	18"CB Low Bw	
712	18"CB Low Eg	
713	20"CB Low Bw	
714	20"CB Low Eg	
715	20"U-China	
716	20"PowerChBw	
717	20"PowerChSh	
718	20"PowerChEg	
STACKED CYMBAL		
719	16"Stackd Bw	
720	16"Stackd Eg	
721	18"Stackd Bw	
722	18"Stackd Eg	
723	China PgBack	
724	Crash PgBack	
RIDE A		
725	20"CustmRd	*P
726	20"CustmRdB	
727	20"CustmRdEg	

No.	Name	Remarks
728	21"StdioRd	*P
729	21"StdioRdB	
730	21"StdioRdEg	
731	20"P-MedRd	*P
732	20"P-MedRdB	
733	20"P-MedRdEg	
734	20"Dark Rd	*P
735	20"Dark RdB	
736	20"Dark RdEg	
737	20"ExHvyRd	*P
738	20"ExHvyRdB	
739	20"ExHvyRdEg	
RIDE B		
740	20"JazZ Rd	*P
741	20"JazZ RdB	
742	20"JazZ RdEg	
743	20"HvyDKRd	*P
744	20"HvyDKRdB	
745	20"HvyDKRdEg	
746	20"ASpecRd	*P
747	20"ASpecRdB	
748	20"ASpecRdEg	
749	20"KSpecRd	*P
750	20"KSpecRdB	
751	20"KSpecRdEg	
752	20"VntZ Rd	*P
753	20"VntZ RdB	
754	20"VntZ RdEg	
755	19"JzCrsRd	*P
756	19"JzCrsRdB	
757	19"JzCrsRdEg	
758	19"P-CrsRd	*P
759	19"P-CrsRdB	
760	19"P-CrsRdEg	
761	18"PRideRd	*P
762	18"PRideRdB	
763	18"PRideRdEg	
764	18"Bop Rd	*P
765	18"Bop RdB	
766	18"Bop RdEg	
767	20"HeavyRd	*P
768	20"HeavyRdB	
769	20"HeavyRdEg	
770	20"Med Rd	*P
771	20"Med RdB	
772	20"Med RdEg	
773	20"TurkyRd	*P

No.	Name	Remarks
774	20"TurkyRdB	
775	20"TurkyRdEg	
776	19"NY Rd	*P
777	19"NY RdB	
778	19"NY RdEg	
779	20"Lite Rd	*P
780	20"Lite RdB	
781	20"Lite RdEg	
782	22"CleanRd	*P
783	22"CleanRdB	
784	22"CleanRdEg	
785	18"FormuRd	*P
786	18"FormuRdB	
787	18"FormuRdEg	
788	20"Bell Rd	*P
789	20"Bell RdB	
790	20"Bell RdEg	
791	Brush Rd	
792	Brush RdEg	
793	Mallet1 Rd	
794	Mallet2 Rd	
PERCUSSION		
795	Bongo Hi	
796	Bongo HiSlap	
797	Bongo Lo	
798	Bongo LoSlap	
799	Bongo2HiOpen	
800	Bongo2HiSlap	
801	Bongo2LoOpen	
802	Bongo2LoSlap	
803	Conga Hi	
804	Conga HiMute	
805	Conga HiSlap	
806	Conga Lo	
807	Conga LoMute	
808	Conga2HiGlis	
809	Conga2HiOpen	
810	Conga2HiSlap	
811	Conga2LoOpen	
812	Conga2LoSlap	
813	Timbale Hi	
814	Timbale HiRm	
815	Timbale Lo	
816	TimbalePaila	
817	Timbale2Hi	
818	Timbale2HiRm	
819	Timb2HiPaila	

Drum Instrument List

No.	Name	Remarks
820	Timbale2Lo	
821	Timbale2LoRm	
822	Timb2LoPaila	
823	Guiro Long	
824	Guiro Short	
825	VibraSlap	
826	Cowbell Hi	
827	Cowbell Lo	
828	Cowbell Mute	
829	CowbellMambo	
830	Claves	
831	SquareBlock	
832	Block Hi	
833	Block Lo	
834	Maracas	
835	Caxixi	
836	Shaker	
837	Tambourine1	
838	Tambourine2	
839	Tambourine3	
840	Tambourine4	
841	TambStick	
842	TambShake	
843	MetalCrasher	
844	6"CrossCym	
845	8"CrossCym	
846	Pandeiro	
847	PandeiroMute	
848	PandeiroSlap	
849	Pandeiro2	
850	Pande2 Slap	
851	Pande2 Close	
852	Pande2 Edge	
853	Pande2 Roll1	
854	Pande2 Roll2	
855	Caixa	
856	Caixa Rim	
857	Agogo Hi	
858	Agogo Lo	
859	Cabasa	
860	Cabasa2	
861	Cuica Hi	
862	Cuica Lo	
863	Cuica Acc	
864	Surdo Hi	
865	Surdo HiMute	
866	Surdo Lo	

No.	Name	Remarks
867	Surdo LoMute	
868	Whistle	
869	WhistleShort	
870	Cajon Bass	
871	Cajon Mute	
872	Cajon Slap	
873	Cajon2 Bass	
874	Cajon2 Close	
875	Cajon2 Open	
876	Cajon2 Slap	
877	Djembe Tone	
878	Djembe Slap	
879	Djembe Bass	
880	Djembe2 Bass	
881	Djembe2 Open	
882	Djembe2 Slap	
883	DjembeBsJngl	
884	DjembeOpJngl	
885	DjembeSjJngl	
886	Kenkeni	
887	Sangban	
888	DoumDoumba	
889	BougarabouBs	
890	BougarabouOp	
891	BougarabuoMt	
892	TalkingDr	
893	TalkingDr Up	
894	AfricaCaxixi	
895	Apiyua	
896	Apiyua Mute	
897	Apiyua Slide	
898	AnkleBeads	
899	AfricaJingle	
900	RainStick	
901	Bendir	
902	Darabuka Dom	
903	Darabuka Tak	
904	Sagat Close	
905	Sagat Open	
906	Tabla Na	
907	Tabla Te	
908	Tabla Ti	
909	Tabla Tin	
910	Tabla Tun	
911	Baya Ge	
912	Baya Gin	
913	Baya Ka	

No.	Name	Remarks
914	Baya Slide	
915	PotDrum	
916	PotDrum Acc	
917	PotDrum Mute	
918	ChenChen	
919	ChenChen Mt	
920	HiraTaiko	
921	HiraTaikoRim	
922	YaguraTaiko	
923	YaguraTaikoR	
924	NagodoTaiko	
925	NagadoTaikoR	
926	Castanet	
927	WoodBlock	
928	Timpani C	
929	Timpani G	
930	Timpani2 C	
931	Timpani2 G	
932	ConcertBD	
933	ConcertBD Mt	
934	ConcertBD2	
935	ConcertBD2Mt	
936	HandCymbal	
937	HandCymbalMt	
938	Triangle	
939	TriangleCls	
940	Triangle2	
941	Triangle2Cls	
942	Crotale	
943	BellTree	
944	SleighBell	
945	TreeChimes	
946	ThaiGong	
947	TinyGong	
948	Gong	
949	LargeGong	
950	OrchestraHit	
951	SnareRoll	
952	ConcertSnare	
953	SteelDrum	
954	Celesta	
955	Glockenspiel	
956	Kalimba	
957	Marimba	
958	TubularBell	
959	Vibraphone	
960	Xylophone	

Drum Instrument List

No.	Name	Remarks
PERC ELECTRONIC		
961	CR78Cowbell	
962	CR78Guiro	
963	CR78Maracas	
964	CR78MtlBeat	
965	CR78Tamb	
966	TR808Clap	
967	TR808Claves	
968	TR808Cowbell	
969	TR808Maracas	
970	TR808XStick	
971	TR909Clap	
SFX		
972	TickDynamic	
973	TickVerb	
974	TickVerb2	
975	Tick	
976	Chick	
977	Random	
978	ReverbSlap	
979	Hammer	
980	Anvil	
981	MetalDoor	
982	MetalPhase	
983	RvsMtlFaze	
984	WhiteLazer	
985	CosmicWater	
986	CosmicDrip	
987	CosmicClaps	
988	CosmicChirp	
989	Falling	
990	FlyAway	
991	BounceDown	
992	TimeTunnel1	
993	TimeTunnel2	
994	SpaceTrip	
995	Growl	
996	Ripping	
997	SpaceAlien	
998	SpaceWarp	
999	Shake	
1000	ShakeDown	
1001	Gear	
1002	GearLong	
1003	Hi-Q	
1004	Poa	
1005	Pyon	

No.	Name	Remarks
1006	Picoon	
1007	Byon	
1008	Kyun	
1009	Psyun	
1010	Boom	
1011	SuperLow	
1012	TimeWarp1	
1013	TimeWarp2	
1014	Transform1	
1015	Transform2	
1016	Transform3	
1017	Tekno FX1	
1018	Tekno FX2	
1019	Tekno FX3	
1020	Ring FX	
1021	Drop Out	
1022	LaserGun	
1023	Spiral	
1024	Emergency	
1025	Wonderer	
OTHER		
1026	Click	
1027	Beep	
1028	Sticks	
1029	Sticks2	
1030	MetroBell	
1031	MetroClick	
1032	R8Slap	
1033	Motor	
1034	Engine	
1035	Glass	
1036	Burt	
1037	Boing1	
1038	Boing2	
1039	Bounce	
1040	IronWhip	
1041	Ratchet	
1042	Drawer	
1043	Explosion	
1044	VerbyHit	
1045	AfroStomp	
1046	Bomb!	
1047	TuningTom	
1048	Scratch1	
1049	Scratch2	
1050	Scratch3	
1051	Scratch4	

No.	Name	Remarks
1052	TapeStop	
1053	TapeRewind	
1054	Voice OK	
1055	Voice Yeah	
1056	Vocoder1	
1057	Vocoder2	
1058	Revs Kick	
1059	Revs Snare	
CLAP		
1060	Clap	
1061	Trio Claps	
1062	Group Claps	
1063	High Claps	
1064	Mid Claps	
1065	Low Claps	
1066	Hi-Q Claps	
1067	Reverb Claps	
1068	Room Claps	
1069	Verb1 Claps	
1070	Verb2 Claps	
1071	Finger Snaps	
CYMBAL EFFECTS		
1072	ElecRide	
1073	ElecRide Bl	
1074	ElecRide Eg	
1075	FX SlickRd	
1076	FX SlickRdBl	
1077	FX SlickRdEg	
1078	PhaseCrash	
1079	PhaseRide	
1080	Revs1 Crash	
1081	Revs2 Crash	
1082	Revs1 China	
1083	Revs2 China	

Drum Instrument List

No.	Name	Remarks
MELODIC		
1084	AcousGuitar	
1085	FingerBass	
1086	SlapBass	
1087	TeknoHit	
1088	PhillyHit	
1089	FunkHit	
1090	Bass Gliss	
1091	Guitar Gliss	
1092	GuitarScratch	
1093	CutGt Down	
1094	CutGt Up	
1095	WahGt1 Down	
1096	WahGt1 Up	
1097	WahGt2 Down	
1098	WahGt2 Up	
1099	Sine 440Hz	
1100	For PadCheck	
1101	Impulse	
OFF		
1102	Off	

Symbols in the remarks column

Symbol	Explanation
*P (Position)	Can get various changes of the sound in accordance with the positioning where on the pad you hit with a stick. In rim sounds, can get such various changes of the sound in accordance with the depth of the stick on the rim.
*X (XStick)	When the Cross Stick Switch is turned ON, it makes possible to use both "Rim Shot" and "Cross Stick" on the rim.
*B (Brush)	Can be played using "Brush Sweep."

* For details on how the trigger input corresponds to your performance technique and striking position, refer to "Trigger Inputs and Playing Methods Corresponding Chart" in the TD-30 owner's manual.

About the sound names

The characters at the end of the sound name designate the type of sound.

Sound	Characters	Type of sound
Snare sounds	S	Head sound of snare
	SR	Rim sound of snare
	XStk	Cross stick sound of snare
Tom sounds	T1	Head sound of tom 1
	T1R	Rim sound of tom 1
Hi-hat sounds	HB	Bow sound of hi-hat
	HE	Edge sound of hi-hat
Cymbal sounds	Bw	Bow sound of cymbal
	Bl	Bell sound of cymbal
	Eg	Edge sound of cymbal

Percussion Set List

Note number	1. Latin Toys	2. Indian Perc	3. African Perc	4. Salsa	
C-1	0	Bass Gliss	←	←	Off
	1	GuitarScrth	←	←	Off
	2	WahGt1 Down	←	←	Off
	3	WahGt1 Up	←	←	Off
	4	WahGt2 Down	←	←	Off
	5	WahGt2 Up	←	←	Off
	6	CR78Guiro	←	←	Off
	7	CR78Tamb	←	←	Off
	8	TR808Clap	←	←	Off
	9	TR808Cowbell	←	←	Off
	10	TR808Maracas	←	←	Off
	11	TR909Clap	←	←	Off
C0	12	Hi-Q	←	←	Off
	13	R8Slap	←	←	Off
	14	Scratch2	←	←	Off
	15	Scratch3	←	←	Off
	16	Sticks	←	←	Off
	17	Click	←	←	Off
	18	MetroClick	←	←	Off
	19	MetroBell	←	←	Off
	20	Clap	←	←	Off
	21	VibraSlap	←	←	Off
	22	SquareBlock	TriangleCls	Cabasa	Bongo Hi
	23	Off	Off	Off	Bongo HiSlap
C1	24	Beep	←	←	Bongo Lo
	25	Crotale	20"Med RdBl	←	Bongo LoSlap
	26	SquareBlock	Triangle	Cabasa	Cabasa
	27	6"SplazhSpEg	6"SplazhSpEg	Triangle2	Conga HiMute
	28	6"SplazhSpBw	6"SplazhSpBw	Triangle2Cls	Conga HiSlap
	29	Guiro Short	TinyGong	VibraSlap	Conga Lo
	30	Guiro Long	Gong	AfroStomp	Conga LoMute
	31	Cuica Hi	PotDrum	Block Hi	Cajon Bass
	32	Cuica Lo	PotDrum Acc	Block Lo	Cajon Mute
	33	Cowbell Hi	Tambourine2	←	Cajon Slap
	34	Cowbell Lo	Tambourine3	←	Cowbell Hi
	35	Cowbell Lo	PotDrum	Djembe Bass	Cowbell Lo
C2	36	Cowbell Mute	Baya Ge	Djembe Bass	CowbellMambo
	37	Tambourine1	Tabla Tin	Djembe Slap	CowbellMambo
	38	Tambourine2	Tabla Na	Djembe Tone	Pandeiro
	39	Conga LoMute	Baya Slide	PotDrum Acc	Surdo LoMute
	40	Tambourine1	Tabla Tin	Djembe Slap	PandeiroSlap
	41	Conga Lo	Baya Ge	PotDrum Mute	Surdo Lo
	42	Claves	TriangleCls	Caxixi	Maracas
	43	Conga Hi	Baya Gin	PotDrum	Surdo Hi
	44	Claves	TriangleCls	Caxixi	Shaker
	45	Bongo Lo	Tabla Tun	TalkingDr	Timbale Lo
	46	Claves	Triangle	Caxixi	Shaker
	47	Bongo LoSlap	FingerSnaps	TalkingDr Up	TimbalePaila
C3	48	Bongo Hi	Tabla Ti	TalkingDr	Timbale Hi
	49	Triangle	Crotale	SleighBell	Guiro Short
	50	Bongo HiSlap	Tabla Te	TalkingDr Up	Timbale HiRm
	51	SleighBell	ThaiGong	Kalimba	WhistleShort
	52	Agogo Lo	Agogo Lo	Cowbell Lo	Cuica Lo
	53	BellTree	ThaiGong	Kalimba	VibraSlap
	54	Tambourine1	←	←	Agogo Hi
	55	TriangleCls	TreeChimes	←	Guiro Long
	56	Cowbell Mute	←	←	Cabasa
	57	Agogo Hi	Crotale	Cowbell Hi	Cuica Hi
	58	Conga HiSlap	Baya Ka	PotDrum Acc	Surdo HiMute
	59	TreeChimes	ThaiGong	Kalimba	Whistle
C4	60	Bongo Hi	←	←	Pandeiro
	61	Bongo Lo	←	←	PandeiroMute
	62	Conga Hi	←	←	PandeiroSlap
	63	Conga HiSlap	←	←	Surdo Hi
	64	Conga Lo	←	←	Surdo HiMute

Note number
65-127



Percussion Set List


Note number	5. SFX	6./7./8. Perc Set	Drum kit (factory settings)
C-1	0	Off	Bass Gliss
	1	Off	GuitarScratch
	2	Off	WahGt1 Down
	3	Off	WahGt1 Up
	4	Off	WahGt2 Down
	5	Off	WahGt2 Up
	6	Off	CR78Guiro
	7	Off	CR78Tamb
	8	Off	TR808Clap
	9	Off	TR808Cowbell
	10	Off	TR808Maracas
	11	Off	TR909Clap
C0	12	Off	Hi-Q
	13	Off	R8Slap
	14	Off	Scratch2
	15	Off	Scratch3
	16	Off	Sticks
	17	Off	Click
	18	Off	MetroClick
	19	Off	MetroBell
	20	Off	Clap
	21	Off	VibraSlap
	22	Off	Off
	23	Off	(7) Closed HH Rim (for Brush Sweep)
C1	24	Hi-Q	Beep
	25	Poa	Off
	26	Pyon	Off
	27	Picoon	Off
	28	Byon	Off
	29	Kyun	Off
	30	Psyun	Off
	31	Boom	Off
	32	SuperLow	Off
	33	TimeWarp1	Off
	34	TimeWarp2	Off
	35	Transform1	Off
C2	36	Transform2	Off
	37	Transform3	Off
	38	Tekno FX1	Off
	39	Tekno FX2	Off
	40	Tekno FX3	Off
	41	Ring FX	Off
	42	Drop Out	Off
	43	LaserGun	Off
	44	Spiral	Off
	45	Emergency	Off
	46	Wonderer	Off
	47	Click	Off
C3	48	Beep	Off
	49	Sticks	Off
	50	Sticks2	Off
	51	MetroBell	Off
	52	MetroClick	Off
	53	FingerSnaps	Off
	54	Clap	Tambourine1
	55	R8Slap	Off
	56	Motor	Cowbell Mute
	57	Engine	Off
	58	Glass	Off
	59	Burt	Off
C4	60	Boing1	Bongo Hi
	61	Boing2	Bongo Lo
	62	Bounce	Conga Hi
	63	VerbyHit	Conga HiSlap
	64	AfroStomp	Conga Lo

Note number
65-127




Percussion Set List

Note number	1. Latin Toys	2. Indian Perc	3. African Perc	4. Salsa
65	Timbale Hi	←	←	Surdo Lo
	66 Timbale Lo	←	←	Surdo LoMute
67	Agogo Hi	←	←	Whistle
	68 Agogo Lo	←	←	WhistleShort
69	Cabasa	←	←	VibraSlap
70	Maracas	←	←	Tabla Na
	WhistleShort	←	←	Tabla Te
C5 72	Whistle	←	←	Tabla Ti
	73 Guiro Short	←	←	Tabla Tin
74	Guiro Long	←	←	Tabla Tun
75	Claves	←	←	Baya Ge
	Block Hi	←	←	Baya Gin
76	Block Lo	←	←	Baya Ka
77	78 Cuica Hi	←	←	Baya Slide
	Cuica Lo	←	←	PotDrum
79	80 TriangleCls	←	←	PotDrum Acc
	Triangle	←	←	PotDrum Mute
81	82 Shaker	←	←	Djembe Tone
	SleighBell	←	←	Djembe Slap
C6 84	BellTree	←	←	Djembe Bass
	85 Castanet	←	←	TalkingDr
86	Surdo LoMute	←	←	TalkingDr Up
87	Surdo Lo	←	←	Castanet
	Bongo HiSlap	←	←	WoodBlock
88	Bongo LoSlap	←	←	Timpani C
89	90 Conga HiMute	←	←	Timpani G
	Conga LoMute	←	←	ConcertBD
91	92 PandeiroMute	←	←	ConcertBD Mt
	Pandeiro	←	←	HandCymbal
93	94 PandeiroSlap	←	←	HandCymbalMt
	TreeChimes	←	←	Triangle
C7 96	Crotale	←	←	TriangleCls
	97 Gong	←	←	Triangle2
98	Cajon Bass	←	←	Triangle2Cls
99	Cajon Mute	←	←	Crotale
	Cajon Slap	←	←	BellTree
100	CowbellMambo	←	←	SleighBell
101	102 SquareBlock	←	←	TreeChimes
	Caxixi	←	←	ThaiGong
103	104 Timbale HiRm	←	←	TinyGong
	TimbalePaila	←	←	Gong
105	106 Cuica Acc	←	←	OrchestraHit
	Surdo Hi	←	←	SnareRoll
C8 107	Surdo HiMute	←	←	ConcertSnare
	109 PotDrum	←	←	SteelDrum
110	PotDrum Acc	←	←	Celesta
111	PotDrum Mute	←	←	Glockenspiel
	Djembe Tone	←	←	Kalimba
112	Djembe Slap	←	←	Marimba
113	114 Djembe Bass	←	←	TubularBell
	TalkingDr	←	←	Vibraphone
115	116 TalkingDr Up	←	←	Xylophone
	Tabla Na	←	←	CR78Cowbell
117	118 Tabla Te	←	←	CR78Guiro
	Tabla Ti	←	←	CR78Maracas
C9 119	Tabla Tun	←	←	CR78MtlBeat
	121 Baya Ge	←	←	CR78Tamb
122	Baya Gin	←	←	TR808Clap
123	Baya Ka	←	←	TR808Claves
	Baya Slide	←	←	TR808Cowbell
124	ConcertBD	←	←	TR808Maracas
125	126 HandCymbal	←	←	TR808XStick
	Off	←	←	TR909Clap
127				



Percussion Set List

Note number	5. SFX	6./7./8. Perc Set	Drum kit (factory settings)
65	Bomb!	Timbale Hi	
66	TuningTom	Timbale Lo	
67	ReverseCrash	Agogo Hi	
68	ReverseChina	Agogo Lo	
69	PhaseCrash	Cabasa	
70	PhaseRide	Maracas	
71	Scratch1	WhistleShort	
72	Scratch2	Whistle	
73	Scratch3	Guiro Short	
74	Scratch4	Guiro Long	
75	TapeStop	Claves	
76	TapeRewind	Block Hi	
77	Voice OK	Block Lo	
78	Voice Yeah	Cuica Hi	
79	Vocoder1	Cuica Lo	
80	Vocoder2	TriangleCls	
81	TeknoHit	Triangle	
82	PhillyHit	Shaker	
83	FunkHit	SleighBell	
84	Bass Gliss	BellTree	
85	Guitar Gliss	Castanet	
86	GuitarScratch	Surdo LoMute	
87	CutGt Down	Surdo Lo	
88	CutGt Up	Bongo HiSlap	
89	WahGt1 Down	Bongo LoSlap	
90	WahGt1 Up	Conga HiMute	
91	WahGt2 Down	Conga LoMute	
92	WahGt2 Up	PandeiroMute	
93	Sine 440Hz	Pandeiro	
94	For PadCheck	PandeiroSlap	
95	Off	TreeChimes	
96	Off	Crotale	
97	Off	Gong	
98	Off	Cajon Bass	
99	Off	Cajon Mute	
100	Off	Cajon Slap	
101	Off	CowbellMambo	
102	Off	SquareBlock	
103	Off	Caxixi	
104	Off	Timbale HiRm	
105	Off	TimbalePaila	
106	Off	Cuica Acc	
107	Off	Surdo Hi	
108	Off	Surdo HiMute	
109	Off	PotDrum	
110	Off	PotDrum Acc	
111	Off	PotDrum Mute	
112	Off	Djembe Tone	
113	Off	Djembe Slap	
114	Off	Djembe Bass	
115	Off	TalkingDr	
116	Off	TalkingDr Up	
117	Off	Tabla Na	
118	Off	Tabla Te	
119	Off	Tabla Ti	
120	Off	Tabla Tun	
121	Off	Baya Ge	
122	Off	Baya Gin	
123	Off	Baya Ka	
124	Off	Baya Slide	
125	Off	ConcertBD	
126	Off	HandCymbal	
127	Off	←	



Backing Instrument List

PC	CC0	Name	VOICES
PIANO			
1	0	PIANO 1	1
	8	PIANO 1W	2
	16	PIANO 1D	1
2	0	PIANO 2	1
	8	PIANO 2W	2
3	0	PIANO 3	1
	8	PIANO 3W	2
4	0	HONKY-TONK	2
	8	HONKY-TONK W	2
E. PIANO			
5	0	E.PIANO 1	1
	8	DETUNED EP 1	2
	24	60'S E.PIANO	1
	64	FM+SA EP	2
6	65	HARD EP	2
	0	E.PIANO 2	2
	64	BRIGHT FM EP	2
CLAVI			
7	0	HARPSICHORD	1
	8	COUPLED HPS.	2
	16	HARPSI.W	2
8	24	HARPSI.O	2
	0	CLAV.	1
	64	FUNK CLAV.	2
CHROMATIC PERCUSSION			
9	0	CELESTA	1
10	0	GLOCKENSPIEL	1
11	0	MUSIC BOX	1
12	0	VIBRAPHONE	1
	8	VIB.W	2
13	0	MARIMBA	1
14	0	XYLOPHONE	1
15	0	TUBULAR-BELL	1
	8	CHURCH BELL	1
	9	CARILLON	1
16	0	SANTUR	1

PC	CC0	Name	VOICES
ORGAN			
17	0	ORGAN 1	1
	8	DETUNED OR.1	2
	16	60'S ORGAN 1	1
	32	ORGAN 4	2
	64	SC88 ORGAN 4	1
18	65	EVEN BAR	2
	0	ORGAN 2	1
	8	DETUNED OR.2	2
19	32	ORGAN 5	2
	0	ORGAN 3	2
20	0	CHURCH ORG.1	1
	8	CHURCH ORG.2	2
	16	CHURCH ORG.3	2
21	0	REED ORGAN	1
22	0	ACCORDION FR	2
	8	ACCORDION IT	2
23	0	HARMONICA	1
24	0	BANDONEON	2
GUITAR			
25	0	NYLON-STR.GT	1
	0	STEEL-STR.GT	1
	8	12-STR.GT	2
26	64	NYLON+STEEL	2
	0	JAZZ GT.	1
27	8	HAWAIIAN GT.	1
	0	CLEAN GT.	1
28	8	CHORUS GT.	2
	0	MUTED GT.	1
29	64	MUTED GT.2	2
	65	POP GT.	1
	66	FUNK GT.	1*
	67	FUNK GT.2	1*
30	0	OVERDRIVE GT	1
	64	FDBK.ODRV.GT	2
31	0	DISTORTIONGT	1
	8	FEEDBACK GT.	2
	64	HEAVY GT.	1
	65	FDBK. HVY.GT	2
	66	MUTED DIS.GT	1
32	67	ROCK RHYTHM	2
	0	GT.HARMONICS	1
	8	GT. FEEDBACK	1
BASS			
33	0	ACOUSTIC BS.	2
	64	ELCTRC.AC.B5	2

PC	CC0	Name	VOICES
34	0	FINGERED BS.	1
	64	FUNK BASS	2
	65	REGGAE BASS	2
35	0	PICKED BS.	1
	64	MUTE PICKBS1	1
	65	MUTE PICKBS2	1
36	0	FRETLESS BS.	1
	0	SLAP BASS 1	1
37	64	SLAP BASS 3	1
	65	RESO SLAP	1
	66	SLAP BASS 4	1
	38	0	SLAP BASS 2
SYN. BASS			
39	0	SYNTH BASS 1	1
	1	SYNTHBASS101	1
	8	SYNTH BASS 3	1
	64	TB33 BS 1	1
	65	TB33 BS 2	1
	66	TB33 BS 3	1
40	0	SYNTH BASS 2	2
	16	RUBBER BASS	2
	64	SH101 BS 1	1
	65	SH101 BS 2	1
	66	SH101 BS 3	1
	67	MODULAR BASS	2
ORCHESTRA			
41	0	VIOLIN	1
	8	SLOW VIOLIN	1
42	0	VIOLA	1
43	0	CELLO	1
44	0	CONTRABASS	1
45	0	TREMOLO STR	1
46	0	PIZZICATO STR	1
47	0	HARP	1
48	0	TIMPANI	1
STRINGS			
49	0	STRINGS	1
	8	ORCHESTRA	2
50	0	SLOW STRINGS	1
51	0	SYN.STRINGS1	1
	8	SYN.STRINGS3	2
	64	SYN.STRINGS4	2
	65	OB STRINGS	2
52	0	SYN.STRINGS2	2
53	0	CHOIR AAHS	1
	32	CHOIR AAHS 2	1
54	0	VOICE OOHs	1

Backing Instrument List

PC	CC0	Name	VOICES
55	0	SYNVOX	1
56	0	ORCHESTRAHIT	2
BRASS			
57	0	TRUMPET	1
58	0	TROMBONE	1
	1	TROMBONE 2	2
59	0	TUBA	1
60	0	MUTEDTRUMPET	1
61	0	FRENCH HORN	2
	1	FR.HORN 2	2
62	0	BRASS 1	1
	8	BRASS 2	2
SYN. BRASS			
63	0	SYNTH BRASS1	2
	8	SYNTH BRASS3	2
	16	ANALOGBRASS1	2
	64	SYNTH BRASS5	2
	65	POLY BRASS	2
	66	QUACK BRASS	2
	67	OCTAVE BRASS	2
64	0	SYNTH BRASS2	2
	8	SYNTH BRASS4	1
	16	ANALOGBRASS2	2
	64	SOFT BRASS	2
	65	VELO BRASS 1	2
	66	VELO BRASS 2	2
REED			
65	0	SOPRANO SAX	1
66	0	ALTO SAX	1
67	0	TENOR SAX	1
68	0	BARITONE SAX	1
69	0	OBOE	1
70	0	ENGLISH HORN	1
71	0	BASSOON	1
72	0	CLARINET	1
PIPE			
73	0	PICCOLO	1
74	0	FLUTE	1
75	0	RECORDER	1
76	0	PAN FLUTE	1
77	0	BOTTLE BLOW	2
78	0	SHAKUHACHI	2
79	0	WHISTLE	1
80	0	OCARINA	1

PC	CC0	Name	VOICES
SYN. LEAD			
81	0	SQUARE WAVE	2
	1	SQUARE	1
	8	SINE WAVE	1
82	0	SAW WAVE	2
	1	SAW	1
	8	DOCTOR SOLO	2
	64	BIG LEAD	2
83	65	WASPY SYNTH	2
	0	SYN.CALLIOPE	2
84	0	CHIFFER LEAD	2
	0	CHARANG	2
85	64	DIST. LEAD 1	2
	65	DIST. LEAD 2	2
	66	FUNK LEAD	2
86	0	SOLO VOX	2
	0	5TH SAW WAVE	2
87	64	BIG FIVES	2
	0	BASS & LEAD	2
88	64	BIG & RAW	2
	65	FAT & PERKY	2
	SYN. PAD		
89	0	FANTASIA	2
	0	WARM PAD	1
	64	THICK PAD	2
90	65	HORN PAD	2
	0	POLYSYNTH	2
91	64	80'S POLYSYN	2
	0	SPACE VOICE	1
92	0	BOWED GLASS	2
93	0	METAL PAD	2
	64	PANNER PAD	2
94	0	HALO PAD	2
	0	SWEEP PAD	1
95	64	POLAR PAD	1
	65	CONVERGE	1
SYN. SFX			
97	0	ICE RAIN	2
	0	SOUNDTRACK	2
98	64	ANCESTRAL	2
	65	PROLOGUE	2
99	0	CRYSTAL	2
	1	SYN MALLET	1
100	0	ATMOSPHERE	2
101	0	BRIGHTNESS	2
102	0	GOBLIN	2

PC	CC0	Name	VOICES
103	0	ECHO DROPS	1
	1	ECHO BELL	2
	2	ECHO PAN	2
	64	ECHO PAN 2	2
	65	BIG PANNER	2
	66	RESO PANNER	2
104	0	STAR THEME	2
ETHNIC MISC			
105	0	SITAR	1
	1	SITAR 2	2
106	0	BANJO	1
107	0	SHAMISEN	1
108	0	KOTO	1
	8	TAISHO KOTO	2
109	0	KALIMBA	1
110	0	BAGPIPE	1
111	0	FIDDLE	1
112	0	SHANAI	1
PERCUSSIVE			
113	0	TINKLE BELL	1
114	0	AGOGO	1
115	0	STEEL DRUMS	1
116	0	WOODBLOCK	1
	8	CASTANETS	1
117	0	TAIKO	1
	8	CONCERT BD	1
118	0	MELO. TOM 1	1
	8	MELO. TOM 2	1
119	0	SYNTH DRUM	1
	8	808 TOM	1
	9	ELEC PERC.	1
120	0	REVERSE CYM.	1
GUITAR BASS FX			
121	0	GT.FRETNOISE	1
	1	GT.CUT NOISE	1
	64	WAH BRUSH GT	1
	65	GT. SLIDE	1
	66	GT. SCRATCH	1
	67	BASS SLIDE	1
	SFX		
122	0	BREATH NOISE	1
	1	FL.KEY CLICK	1
123	0	SEASHORE	1
	1	RAIN	1
	2	THUNDER	1
	3	WIND	1
	5	BUBBLE	2

Backing Instrument List

PC	CC0	Name	VOICES
124	0	BIRD	2
	1	DOG	1
	3	BIRD 2	1
125	0	TELEPHONE 1	1
	1	TELEPHONE 2	1
	3	DOOR	1
	5	WIND CHIMES	2
126	0	HELICOPTER	1
	2	CAR-STOP	1
	9	BURST NOISE	2
	64	SPACE TRI.	1
127	0	APPLAUSE	2
	3	PUNCH	1
128	0	GUN SHOT	1
	2	LASERGUN	1
	3	EXPLOSION	2

***:** VELOCITY SWITCH

The tone switches at velocity 116.

PC: Program number (Instrument number)

CC0: Value of control change number 0

VOICES: Number of voices used

* To switch instruments from the external MIDI device, send "0" on the CC32# (Control Change Bank Select) from the external MIDI device to the TD-30.

* The value of the CC32# (Control Change Bank Select) that the TD-30 transmits is always "0".

Preset Pattern List

No.	Name	Time Signature	Length	Tempo	Play Type
1	Preview	4/4	13	114	Loop
2	Preview Jazz	4/4	16	138	Loop
3	SoundCheck 1	4/4	4	114	Loop
4	SoundCheck 2	4/4	4	114	Loop
5	SoundCheck 3	4/4	4	114	Loop
6	Drum Solo	4/4	7	114	Loop
7	IntoTheTrash	4/4	50	135	1Shot
8	Night Breeze	4/4	44	95	1Shot
9	Salsa Freak	4/4	42	115	1Shot
10	Pop Sixteen	4/4	8	80	Loop
11	Shuffle Pop	4/4	8	88	Loop
12	Shuffle Rock	4/4	32	141	Loop
13	Prog Metal	4/4	8	120	Loop
14	Fusion Mood	4/4	16	84	Loop
15	2Maro Fusion	4/4	48	220	Loop
16	7/4 Groove	7/8	8	110	Loop
17	4/4 Groove	4/4	8	110	Loop
18	5/4 Beat	5/4	8	200	Loop
19	Be-Boppin'	4/4	48	220	Loop
20	Big Band	4/4	16	100	Loop
21	Country Daze	4/4	8	120	Loop
22	Samba Fusion	4/4	16	120	Loop
23	Drum'n Bass	4/4	32	170	Loop
24	Dub Stepper	4/4	16	140	Loop
25	Trance Out	4/4	16	130	Loop
26	Hip Hop Road	4/4	8	108	Loop
27	R&B Hop	4/4	32	97	Loop
28	Acid Hops	4/4	20	92	Loop
29	LateNiteTalk	4/4	16	95	Loop
30	Suspended	4/4	18	95	Loop
31	R&B Groove	4/4	12	80	Loop
32	Slow Ballad	4/4	22	66	Loop
33	6/8 Ballad	6/8	21	50	Loop
34	7/4 Funk A	7/4	4	110	Loop
35	7/4 Funk B	7/4	4	110	Loop
36	6/8 Jazz	6/8	26	101	Loop
37	Smooth Jazz	4/4	20	183	Loop
38	Blues Latin	4/4	12	55	Loop
39	2-Steppin'	4/4	16	130	Loop
40	Djembe'nBass	4/4	16	154	Loop
41	Kyoto Tale	4/4	16	100	Loop
42	RoyalChord 1	4/4	16	100	Tap
43	RoyalChord 2	4/4	8	100	Tap
44	RoyalChord 3	4/4	2	100	Tap
45	DnB 1Shot A	4/4	8	170	1Shot
46	DnB 1Shot B	4/4	8	170	1Shot
47	DnB 1Shot C	4/4	8	170	1Shot

No.	Name	Time Signature	Length	Tempo	Play Type
48	DnB 1Shot D	4/4	2	170	1Shot
49	Pop Sine 1	4/4	1	80	Tap
50	Pop Sine 2	4/4	1	80	Tap
51	Pop Sine 3	4/4	1	80	Tap
52	Pop Sine 4	4/4	2	80	Tap
53	Pop Loop	4/4	8	80	Loop
54	Pop Bass&EP	4/4	8	80	Tap
55	Pop Fun 1	4/4	1	80	Tap
56	Pop Fun 2	4/4	1	80	Tap
57	Pop Fun 3	4/4	1	80	Tap
58	Pop Strings1	4/4	1	80	Tap
59	Pop Strings2	4/4	1	80	Tap
60	Pop Guitar	4/4	2	80	Tap
61	HARD BassTap	4/4	2	120	Tap
62	SuperLpChord	4/4	12	120	Tap
63	SuperLpOdd	4/4	3	120	Tap
64	SuperLpBass	4/4	2	120	Tap
65	SuperLpSyn1	4/4	3	120	Tap
66	SuperLpSyn2	4/4	6	120	Tap
67	ROBO Chords	4/4	6	120	Tap
68	ROBO Tap	4/4	9	120	Tap
69	FunkyJungl 1	4/4	2	160	Loop
70	FunkyJungl 2	4/4	2	160	Loop
71	FunkySnrRoll	4/4	1	160	Loop
72	D-N-B BREAK	4/4	4	160	Loop
73	Sitar Rag	4/4	17	100	Tap
74	OrchString1	4/4	8	128	Tap
75	OrchString2	4/4	8	128	Tap
76	OrchString3	4/4	8	128	Tap
77	Roll Snr Rim	2/4	1	168	1Shot
78	Roll Tom1Rim	2/4	1	168	1Shot
79	Roll Tom2Rim	2/4	1	168	1Shot
80	Roll Tom3Rim	2/4	1	168	1Shot
81	AsianRoad 1	4/4	24	168	Tap
82	AsianRoad 2	4/4	26	168	Tap
83	AsianRoad 3	4/4	1	168	Tap
84	Melo Arp A1	4/4	6	100	Tap
85	Melo Arp A2	4/4	6	100	Tap
86	Melo Arp B1	4/4	2	100	Tap
87	Melo Arp B2	4/4	1	100	Tap
88	Melo Arp C1	4/4	2	100	Tap
89	Melo Arp C2	4/4	1	100	Tap
90	Melo Chd 1	4/4	8	100	Tap
91	Melo Chd 2	4/4	8	100	Tap
92	Melo Chd 3	4/4	2	100	Tap
93	neo Chord 1	4/4	32	168	Tap
94	neo Chord 2	4/4	16	168	Tap

Preset Pattern List

No.	Name	Time Signature	Length	Tempo	Play Type
95	neo Chord 3	4/4	17	168	Tap
96	Samba	4/4	1	120	Tap
97	KickRimRoll	4/4	1	168	1Shot
98	LayerKickRim	4/4	1	120	Tap
99	MVC 7 Notes	4/4	7	128	MVC
100	MVC 12 Notes	4/4	12	128	MVC

Play Type	Explanation
Loop	When the pattern has played to the end, playback will repeat from the beginning.
1Shot	Playback will stop when the pattern reaches the end.
Tap	If assigned to a pad pattern, the notes within the pattern will play sequentially each time you strike the pad.
MVC	These are patterns for use only with VISUAL CONTROL.

MEMO

For details on Time Signature, Length, and Tempo, refer to "Specifying the Number of Measures, Time Signature, and Tempo (SETUP)" in the TD-30 owner's manual.

Copyrights

- Recording, duplication, distribution, sale, lease, performance, or broadcast of copyrighted material (musical works, visual works, broadcasts, live performances, etc.) belonging to a third party in part or in whole without the permission of the copyright owner is forbidden by law.
- Do not use this product for purposes that could infringe on a copyright held by a third party. We assume no responsibility whatsoever with regard to any infringements of third-party copyrights arising through your use of this product.
- The copyright of content in this product (the sound waveform data, style data, accompaniment patterns, phrase data, audio loops and image data) is reserved by Roland Corporation.
- Purchasers of this product are permitted to utilize said content for the creating, performing, recording and distributing original musical works.
- Purchasers of this product are NOT permitted to extract said content in original or modified form, for the purpose of distributing recorded medium of said content or making them available on a computer network.