

Alarm System with Shock and Glass-Break Protection

ENFORCER® 300L

One of the most complete security systems ever, with dual-stage shock sensor and built-in dual-stage glass-break sensor (with remote microphone). Also includes built-in starter disable and flashing light replays, (+) and (-) outputs for door lock/unlock, domelight control, Automatic Starter Disable, and more.

Features:

- Instant triggering with multiple trigger inputs
- Miniature alarm brain (3 x 2 3/4 x 11/41) with
 - Patented Q.Q.T. for quick & quiet tests
 - Fail-Safe Arming
 - Phase-II Protection
- Two 3-button transmitters
 - New ultra-slim design
 - 200 ft. range. 68 Billion possible codes
 - Code-learn up to 4 transmitters. Codes stored in EEPROM
 - 2nd & 3rd channel output, plus second car operation
 - Chirp delete, zone and sensor bypass, panic via remote
 - RF CodeWash deletes codes of all remotes during code learning to prevent use of lost or stolen remotes
- Dual-Stage shock sensor (patented)
 - Separate pre-intrusion & trigger adjustments
- Dual-stage glass-break sensor
 - Built-in, with easily installed remote microphone
- Multi-tone siren
 - Super-small, 3-tone, 128dB, no litoyl sounds
 - Chirps for armed, disarmed, pre-intrusion alert, sensor & zone bypass
 - Patented Stay-Safe Disarm shuts off sounding siren without disarming the alarm
- 5-function LED
 - Indicates alarm arming, armed, disarmed, valet mode, & RF transmitter reception for troubleshooting
- Multi-function push button (included)
 - For valet, emergency disarm, & one-time override of passive arming



- Flashing parking lights
 - Built-in relay for easy installation
 - Flashes indicated armed, disarmed, valet, pre-intrusion, sensor & zone bypass, trigger, and tamper
 - - + or output, single or dual circuit
- Door lock outputs (+ or -)
 - Lock/unlock doors via remote, even while driving or in valet
 - Programmable ignition-controlled door lock/unlock
 - 2-step door unlock output
- Starter disable
 - Built-in relay for easy installation
 - Programmable Automatic Starter Disable can automatically disable the starter after the engine is turned off even if the user forgets to arm the alarm
- Domelight supervision
 - Turns domelight on for 15 seconds when disarming alarm
- Multiple programming functions:
 - Active/passive arming
 - Chirp/no chirp
 - 0.4/6.4-sec. door lock/unlock output
 - N.O./N.C. trigger input
 - Autolock or active locking of doors
 - Permanent disarm or automatic rearm
 - Current and/or switch sensing (with fan bypass)
 - Ignition lock/unlock on/off
 - Automatic Starter Disable on/off

SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606

Phone: (949) 261-2999 | (800) 662-0800 Fax: (949) 261-7326 Website: www.seco-larm.com Email: sales@seco-larm.com