

Electro-Voice SR50A SoundMate Single Channel Personal Extender (Receiver) A-Band (72.100 MHz/No Earphones)

Type of Receiver	Single Frequency Assistive Listening Receiver
RF Carrier Frequency Range	72 - 76 MHz
Approx. Working Range	Approx. 300'
Overall Frequency Response	100 Hz - 10 kHz, (+/-3dB)
Signal-to-Noise Ratio	Greater than 60 dB
# Of Channels	1 Fixed Channel (Channel 031)
Type of Output(s)	(Recessed) 3.5mm Mini Jack
Headphone Monitoring	Yes, 3.5mm Audio Output NOTE: This Jack Also Serves as the Charger Input
Power Requirements	Two (2) "AA" Batteries
Battery Type/Approx. Life	Two (2) "AA" Batteries/30 Hours Alkaline, 10 Hours NiCad
Display	Backlit On/Tuning Indicator
Mounting Options	Belt or Pocket
Antenna Type	Uses Earphone Wire
Dimensions	4 x 2.75 x 1" (101 x 70 x 25mm)
Weight	Not Specified by Manufacturer
Package Weight	0.28 lb
Box Dimensions (LxWxH)	6.0 x 5.0 x 2.0"