

TASCAM RC-3F 3-Way Footswitch for DP-03/GB-10/LR-10/DR-40

The **RC-3F** is a 3-way footswitch for the GB-10, LR-10, DP-03 and other TASCAM recorders and players. The 2.5mm mini jack plugs into the "remote" jack of these TASCAM products to add features like play/pause, looping or punch in. See the product's user manual for details.

Compatible products:

- SS-R250N
- SS-CDR250N
- CD-500
- CD-500B
- DP-03/DP-03SD
- DP-24/DP-24SD
- DP-32/DP-32SD
- DR-100MKII
- GB-10
- LR-10
- US-366