

## **SWIT S-7005S V-mount Battery Plate for Gold-mount Camera**

### **Adapt V-mount battery to Gold mount camera**

S-7005S is used to adapt V-mount batteries to Panasonic AntonBauer gold mount cameras. The front side is V-mount plate, to attach SONY V-mount batteries, and the rear side is AntonBauer gold mount connection for the Panasonic gold mount cameras.

### **D-tap Output Socket**

The S-7005S adaptor is equipped with a D-tap DC output socket on the side, for simultaneous DC power output to additional on-camera equipment. Nominate voltage is 14.4V

### **Durable Release Button**

S-7005S is equipped with a new battery release button, with outstanding feeling and resilience, and ensures the stable and reliable connectivity of battery.

### **Features:**

- Gold mount camera to use V-mount battery
- New V-mount release button
- D-tap DC output socket
- Smaller in size
- Stable and reliable connectivity