

Roland XI-DANTE Dante Expansion Interface

Dante Expansion Interface

Used in the M-5000

- Primary, Secondary, Control port
- 32 inputs x 32 outputs at 96kHz or 64 inputs x 64 outputs at 48kHz

Used in the V-1200HD

- 16 inputs x 16 outputs at 48kHz

Dante Controller

Dante Controller is a program from Audinate for managing a Dante network and performing tasks such as making audio-routing settings. It is available for Windows and Macintosh. You can download Dante Controller (at no charge) from the following Audinate website.

Dante Virtual Soundcard

Dante Virtual Soundcard is a program from Audinate for operating a computer on a Dante network as a Dante device. It is available for Windows and Macintosh. Using Dante Virtual Soundcard makes it possible to use programs compatible with standard Macintosh Core Audio or ASIO audio interfaces to transmit audio data direct between computers and Dante devices on the network. You can download Dante Virtual Soundcard (purchase required) from the following Audinate website.