

User's Guide

4K HDMI Single Link Optical Extender FTH



Thank you for purchasing FTH

Optical 4K HDMI extender **FTH** extends 4K@30Hz UHD HDMI signal up to 200M using a single strand of multi-mode optic fiber.

www.ophit.com



Check your package

Check the package and make sure you have everything:

Contents

- (1) FTH Transmitter & Receiver
- (2) +5V DC Power supply x 2pcs
- (3) User's Guide

If any of these items are missing in your package, contact OPHIT or your supplier for support.

NOTE: Package content may differ if you have placed a special order or placed order from anywhere other than OPHIT CO., LTD. OPHIT CO., LTD. orders the right to make changes without further notice to a product described herein to improve reliability, design, packaging or function.

nstallation

Installation Steps:

Receiver module.

- 1. Connect the Transmitter module to the HDMI source device.
- 2. Connect the Receiver module to the display.
- Connect a single strands of multi-mode(OM3) LC terminated fiber optic cable(50/125 µm) from the Transmitter to the Receiver module.
- 4. Connect the included +5V DC power supply into Transmitter and
- Blue Active LED indicator on the modules will be light up after all connections are completed.





Warranty

We, OPHIT hereby warrant the final purchase of our product as follows.

In the case of troubles on our products, please contact the shop purchased.

One year limited warranty

Our customers have right to be served with free of charge when there is trouble in this product during 1(one) year from the day purchased.

Out of warranty services

When you request services (in the case of non manufacturing defects but the troubles by misusage), may served with charge as follows.

- Defects of products caused by accident, disaster.
- Damages of products caused by the customer's carelessness or mistaken application.
- Damages of products caused by the application of the parts or products not supplied or sold by our company.
- Damages of products and related defects caused by not our staff or the men or group not nominated by us for services.

The interchanged parts and products for maintenance services shall be replaced as new parts and products operating normally, and the inter-changed parts and products shall be subjected to our company.



Technical and Sales Support

KOREA HQ

OPHIT CO., LTD.

3F Suntechnovil, 5-27 Mangpo-Dong, Youngtong-Gu, Suwon-City, Kyunggi-Do, Korea (443-400)

> Tel: + 82 (0)31 695 5543 Fax: + 82 (0)31 695 5545

> > E-Mail

jhchoi35@ophit.com

Regional Office

HSΔ

Foreseeson Custom Display

2210E, Winston Road Anaheim, CA 92806 USA Tel: +1-714 300 0540 Fax: +1-714 300 0546 E-mail: jhan@foreseesonusa.com

UK Foreseeson UK Ltd

E-mail: leon.bang@fsnmed.eu

Unit 71 Barwell Business Park, Leatherhead road, Chessington, Surrey, KT9 2NY UK Tel: +44 (0)208 546 1047 Fax: +44 (0)208 546 3931

Europe

Foreseeson GmbH

Industriestrasse 38a 63150 Heusenstamm, Germany TEL: +49 (0)6104 64398 0 FAX: +49 (0)6104 6439811 E-mail: christian.elfert@fsnmed.eu

www.ophit.com



