

User's Guide

DP1.2/HDMI 2.0 Converting Splitter



Detections without the second				 OPHIT
	ACTIVE 1	DISPLAYPORT		

Thank you for purchasing DPHS

DPHS is a DisplayPort 1.2a to HDMI 2.0 Converter which receives both video and audio from DisplayPort and converts to HDMI output. And DPHS is included HDMI 2.0 4ch Output Splitter. It's supported HDCP 1.4 and HDCP 2.2 repeater for downstream sink with an embedded key. DPHS has 2 input of DisplayPort and HDMI, the user can select one input.

www.ophit.com



User's Guide

DISPLAIPORT

OPHIT

HDMI

Input Selection

Switch

HEAR

Check your package	Installation
Check the package and make sure you have everything:	Installation Steps:
Contents	1. Connect a source device to DPHS input port.
(1) DPHS Splitter	Connect sink devices to DPHS output port.
(2) +12V DC Power supply x 1pc	Slide the switch to select the input port.
(3) AC 220V Power cord x 1pc	Connect the included +12V DC power supply into the DPHS.
(4) User's Guide	5. LED indicators will be light up after all connections are completed.

DPH

......

DC +12V Power Jack

If any of these items are missing in your package, contact OPHIT or your supplier for support.

NOTE: Package content may differ if you have placed a special order or placed order from anywhere other than OPHIT CO., LTD. OPHIT CO., LTD. reserves the right to make changes without further notice to a product described herein to improve reliability, design, packaging or function.



Warranty

We, OPHIT hereby warrant the final purchase of our product as follows. In the case of troubles on our products, please contact the shop purchased.

One year limited warranty

Our customers have right to be served with free of charge when there is trouble in this product during 1(one) year from the day purchased.

Out of warranty services

When you request services (in the case of non manufacturing defects but the troubles by misusage), may served with charge as follows.

- Defects of products caused by accident, disaster.
- Damages of products caused by the customer's carelessness or mistaken application.
- Damages of products caused by the application of the parts or products not supplied or sold by our company.
- Damages of products and related defects caused by not our staff or the men or group not nominated by us for services.

The interchanged parts and products for maintenance services shall be replaced as new parts and products operating normally, and the inter-changed parts and products shall be subjected to our company.



Technical and Sales Support

KOREA HQ

OPHIT CO., LTD. 3F Suntechnovil, 5-27 Mangpo-Dong, Youngtong-Gu, Suwon-City, Kyunggi-Do, Korea (16681)

> Tel: + 82 (0)31 695 5543 Fax: + 82 (0)31 695 5545

E-Mail jhchoi35@ophit.com

Regional Office

USA

Foreseeson Custom Display 2210E, Winston Road Anaheim, CA 92806 USA Tel: +1 714 300 0540 Fax: +1 714 300 0546 E-mail: inan@foreseesonusa.com

UK

Foreseeson UK Ltd

Unit 2Kingsmill Business Park, Chapel Mill Rd. Kingston Upon Thames, Surrey; KT1 3G2; UK Tel: +44(0) 208 546 1047 Fax: +44(0) 208 546 3931 E-mail: leon.bang@fsnmed.eu

Germany

Foreseeson GmbH Industriestrasse 38a 63150 Heusenstamm Tel: +49(0) 6104 64398 00 Fax: +49(0) 6104 64398 11 E-mail: christian.elfert@fsnmed.eu

www.ophit.com

CE 🗵